UNITED STATES

DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

	ices and Reports on Wells
	5. Lease Number NM-3305% 4
1. Type of Well GAS	6. If Indian, All. or Tribe Name
	7. Unit Agreement Name
2. Name of Operator	
RESOURCES OIL	& GAS COMPANY DECEMBER Well Name & Number
3. Address & Phone No. of Operat PO Box 4289, Farmington, NM	
4. Location of Well, Footage, Se 1850'FSL 850'FEL, Sec.8, T-32	EG., I, R, M
	DICATE NATURE OF NOTICE, REPORT, OTHER DATA
Type of Submission _X_ Notice of Intent	Type of Action Abandonment Change of Plans Recompletion New Construction
Subsequent Report	Plugging Back Non-Routine Fracturing Water Shut off
Final Abandonment	Altering Casing Conversion to Injection
	X Other -
13. Describe Proposed or Comp	
It is intended to install	a pump in the subject well according to the and wellbore diagram.
It is intended to install	a pump in the subject well according to the and wellbore diagram.
It is intended to install	a pump in the subject well according to the and wellbore diagram.
It is intended to install	a pump in the subject well according to the and wellbore diagram.
It is intended to install	leted Operations a pump in the subject well according to the and wellbore diagram.
It is intended to install	a pump in the subject well according to the and wellbore diagram.
It is intended to install attached procedure	a pump in the subject well according to the and wellbore diagram.
It is intended to install attached procedure	leted Operations a pump in the subject well according to the and wellbore diagram. Property of the subject well according to the and wellbore diagram. Property of the subject well according to the and wellbore diagram.

NMOCD

Reggy

Trail Canyon #101 PUMPING UNIT INSTALLATION PROCEDURE

<u>Unit I, Section 8, T32N-R8W, San Juan County, New Mexico</u> <u>Lat. 36.996400 / 36° 59.78'</u> <u>Long. 107.690260 / 107° 41.42'</u>

- 1. MIRU pulling unit.
- 2. NDWH / NUBOP.
- 3. PU donut and TIH to tag for fill.
- 4. TOH standing back 2-3/8" tubing. (Tubing is set @ 3385', there are 110 jts of 2-3/8" 4.7# J-55 with an "F" nipple @ 3353').
- 5. PU 4-3/4" bit on tubing and TIH to PBTD. Circ hole clean. (Note: PBTD is @ ~3387').
- 6. TIH w/ 2-3/8" tubing string and land tubing @ 3382'. Purge valve will be on bottom followed by pup joint, perforated sub, and seating nipple. Space out as needed with pup joints.
- Hang tubing in donut. NDBOP / NUWH.
- 8. TIH w/ new 1.25" top hold down pump, 7/8" Grade D sucker rods (w/ spray metal couplings), polished rod, and polished rod liner. (Note: Vendor contact is listed below).
- 9. Seat the downhole pump, hang horses head, and space out pump.
- 10. Load tubing, and pressure test.
- 11. Start pumping unit and test (adjust spacing if needed).
- 12. RDMO.

COMPLY WITH ALL FEDERAL, STATE AND LOCAL RULES AND REGULATIONS RELATING TO OIL AND GAS OPERATIONS.

Prepared: D.W. Mussett

Pump Vendor:

Energy Pump

Leo Noyes 564-2874

Trail Canyon # 101

Basin Fruitland Coal Unit I, Section 8, T32N, R8W, San Juan County, New Mexico

