

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPPLICATE*
(Other instructions on re-
verse side)

Form approved.
Budget Bureau No. 42 R1424
5. LEASE DESIGNATION AND SERIAL NO.

14-20-604-5546

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. UNIT AGREEMENT NAME
2. NAME OF OPERATOR Aztec Oil & Gas Company	8. FARM OR LEASE NAME Middle Canyon
3. ADDRESS OF OPERATOR P. O. Drawer 570, Farmington, New Mexico	9. WELL NO. #2
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 1830 FSL & 660 FEL, Section 14-32N-15W	10. FILL IN AND POOL, OR WELLS Undesignated Dakota
14. PERMIT NO.	11. SECTION, R., M., OR BLM. SURVEY OR AREA Section 14-32N-15W
15. ELEVATIONS (Show whether DF, RT, GR, etc.)	12. COUNTY OR PARISH, STATE San Juan New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) *

- Spot plug from 3150-3261 (Approximately PBTD) - Perfs & top of Dakota.
- Shoot off casing at approximately 2700' & pull same.
- Spot 100' plug over casing cut-off.
- Spot 100' plug from 1250-1350' - Top of Mancus.
- Spot 70' plug 160-230' - Across Surface Casing Shoe.
- Spot 15 Sx plug in surface & set dry hole marker.
- Fill pits & clean location.
(Fill hole with mud between plugs)



18. I hereby certify that the foregoing is true and correct

SIGNED

[Signature]

TITLE

District Superintendent

DATE June 18

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side