

DIVISION APPROVED PLUGGING PROGRAM

M. J. Miley
Hare (Ransom) #1
N-14-29N-11W

Downhole Equipment - Unknown
Hole Size - Unknown
Total Depth 700'-1021'

- (1) Clean out hole to total depth.
- (2) Set a cement plug from total depth to 600'.
- (3) If well is not cased, set a cement plug 400' to 250'. If well is cased, perforate casing at 400' and set a cement plug 400'-250' in and outside casing.
- (4) Set a cement plug 150'-50'.
- (5) Set a top plug and marker with at least 10 sacks of cement.
- (6) Fill pits, clean and level location.

All plugs will be with Class ~~A, B, or C~~^{Neat} cement with or without an accelerator.

Note: This well may have some type of downhole plug. Blowout prevention equipment must be used.