Submit 3 Copies To Appropriate District	State of New Mexico	Form C-103
Office District I	Energy, Minerals and Natural Resource	es May 27, 2004
1625 N. French Dr., Hobbs, NM 88240		WELL API NO.
District II	OIL CONCEDIVATION DIVICION	т 30-015-10374 чета и до повет и повет
1301 W. Grand Ave., Artesia, NM 88210	OIL CONSERVATION DIVISION	5. Indicate Type of Lease
District III	1220 South St. Francis Dr.	STATE FEE
1000 Rio Brazos Rd., Aztec, NM 87410 District IV	Santa Fe, NM 87505	6. State Oil & Gas Lease No.
1220 S. St. Francis Dr., Santa Fe, NM	· · · · · · · · · · · · · · · · · · ·	BLM Lc-029426-A
6/303		12 14 14 14 14 14 14 14 14 14 14 14 14 14
SUNDRY NOTIC	CES AND REPORTS ON WELLS A	7. Lease Name or Unit Agreement Name
(DO NOT USE THIS FORM FOR PROPOSA	ALS TO DRILL OR TO DEEDEN OR PLUG BACK TO A	
DIFFERENT RESERVOIR. USE "APPLICATION OF THE PROPERTY OF THE P	ATION FOR PERMIT" (FOR C-101) FOR SUMING	✓ West, H. E. "A"
PROPOSALS.) 1. Type of Well: Oil Well (Gas Well 🗷 Other (RECEIVED	West, H. E. "A" 8. Well Number 13
	Gas Well Souther OCD - ARTESIA	99/ 1 0 0 CD ID 31 1 14501
2. Name of Operator		AT/ I
Merit Energy Company	Texas 75240	10. Pool name or Wildcat
3. Address of Operator	T 75240	Crowburg Joseph
13727 Noel Road, Suite 500, Dallas,	, Texas /3240	Grayburg-Jackson
4. Well Location		
Unit Letter :	900 feet from the north line and	2310 feet from the west line
Section 03	Township 17-S Range 31-E	NMPM Eddy County
Section 03	11. Elevation (Show whether DR, RKB, RT, G.	
	11. Elevation (Snow whether DR, RRD, R1, O.	R, etc.)
Pit or Below-grade Tank Application or	Clasura	光彩等的特殊等于
Pit typeDepth to Groundwat	terDistance from nearest fresh water well	Distance from nearest surface water
Pit Liner Thickness: mil	Below-Grade Tank: Volume bb	ols; Construction Material
12 Check A	ppropriate Box to Indicate Nature of No	otice Report or Other Data
12. Check A	ppropriate box to indicate reature of rec	once, Report of Other Data
NOTICE OF INT	FENTION TO:	SUBSEQUENT REPORT OF:
	PLUG AND ABANDON TO REMEDIAL	
PERFORM REMEDIAL WORK		WORK ☐ ALTERING CASING ☐
PERFORM REMEDIAL WORK TEMPORARILY ABANDON	CHANGE PLANS	WORK ALTERING CASING DEDILLING OPNS. PAND A X
PERFORM REMEDIAL WORK	CHANGE PLANS	WORK ☐ ALTERING CASING ☐
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING	CHANGE PLANS	WORK ALTERING CASING DEDILLING OPNS. PAND A X
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER:	CHANGE PLANS	WORK
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or complete	CHANGE PLANS COMMENCE MULTIPLE COMPL CASING/CE OTHER: eted operations. (Clearly state all pertinent deta	WORK ALTERING CASING CE DRILLING OPNS. PAND A X EMENT JOB
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or complete of starting any proposed work.	CHANGE PLANS COMMENCE MULTIPLE COMPL CASING/CE OTHER: eted operations. (Clearly state all pertinent deta	WORK
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or complete	CHANGE PLANS COMMENCE MULTIPLE COMPL CASING/CE OTHER: eted operations. (Clearly state all pertinent deta	WORK ALTERING CASING CE DRILLING OPNS. PAND A X EMENT JOB
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or comple of starting any proposed wor or recompletion.	CHANGE PLANS MULTIPLE COMPL CASING/CE OTHER: eted operations. (Clearly state all pertinent deta k). SEE RULE 1103. For Multiple Completion	WORK ALTERING CASING ALTERING
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or comple of starting any proposed wor or recompletion. 09/22/2006 – Arrive on loc. – Hold ta	CHANGE PLANS MULTIPLE COMPL CASING/CE OTHER: eted operations. (Clearly state all pertinent deta ck). SEE RULE 1103. For Multiple Completion milgate safety meeting. MIRU Royalty Well Server	WORK ALTERING CASING ALTERING
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or comple of starting any proposed wor or recompletion. 09/22/2006 – Arrive on loc. – Hold ta w/2-3/8" tubing. SDFN	CHANGE PLANS MULTIPLE COMPL CASING/CE OTHER: eted operations. (Clearly state all pertinent deta ck). SEE RULE 1103. For Multiple Completion milgate safety meeting. MIRU Royalty Well Service Due to high winds.	WORK ALTERING CASING ALTERING CASING ALTERING OPNS. PAND A X EMENT JOB ALTERING CASING CASING ALTERING CASING CASING CASING CASING CASING CASI
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or comple of starting any proposed wor or recompletion. 09/22/2006 – Arrive on loc. – Hold ta w/2-3/8" tubing. SDFN 09/25/2006 – Hold tailgate safety med	CHANGE PLANS COMMENCE CASING/CE CHER: CHECK OPPL CHER: CHECK OF THER: CHECK OPPL CHER: CHERCH OF THER: CHERCH OF THE CHER	ALTERING CASING DE DRILLING OPNS. PAND A X DEMENT JOB DEMENS: Attach wellbore diagram of proposed completion vice; ND wellhead, & NU BOP's. PU & RIH Existing CIBP @ 3268'. Mix & Pump 25 sxs plug on
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or comple of starting any proposed wor or recompletion. 09/22/2006 – Arrive on loc. – Hold ta w/2-3/8" tubing. SDFN 09/25/2006 – Hold tailgate safety med Top of CIBP @ 3268'.	CHANGE PLANS COMMENCE CASING/CE	ALTERING CASING DE DRILLING OPNS. PAND A X EMENT JOB DE LIIS, and give pertinent dates, including estimated date ins: Attach wellbore diagram of proposed completion vice; ND wellhead, & NU BOP's. PU & RIH existing CIBP @ 3268'. Mix & Pump 25 sxs plug on ring down tubing to 1300'. Mix & Pump 25 sxs cmt.
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or complet of starting any proposed work or recompletion. 09/22/2006 – Arrive on loc. – Hold taw/2-3/8" tubing. SDFN 09/25/2006 – Hold tailgate safety meet Top of CIBP @ 3268'. Plug @ 1300'. POOH	CHANGE PLANS COMMENCE MULTIPLE COMPL OTHER: eted operations. (Clearly state all pertinent deta ck). SEE RULE 1103. For Multiple Completion uilgate safety meeting. MIRU Royalty Well Serve Due to high winds. eting, cont to PU & RIH w/tubing. Tag top of et PU tbg & circ well with P&A mud. POOH lay w/tbg & WOC. RIH w/tbg & tag top of cmt/at	ALTERING CASING DE DRILLING OPNS. PAND A X EMENT JOB DE L'AIS, and give pertinent dates, including estimated date ns: Attach wellbore diagram of proposed completion vice; ND wellhead, & NU BOP's. PU & RIH existing CIBP @ 3268'. Mix & Pump 25 sxs plug on ring down tubing to 1300'. Mix & Pump 25 sxs cmt. 1051'. POOH laying down tbg to 605'. Mix &
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or complet of starting any proposed work or recompletion. 09/22/2006 – Arrive on loc. – Hold taw/2-3/8" tubing. SDFN 09/25/2006 – Hold tailgate safety med Top of CIBP @ 3268'. Plug @ 1300'. POOH Pump a 25 sx cmt plug	CHANGE PLANS MULTIPLE COMPL OTHER: eted operations. (Clearly state all pertinent deta- k). SEE RULE 1103. For Multiple Completion nilgate safety meeting. MIRU Royalty Well Serve Due to high winds. eting, cont to PU & RIH w/tubing. Tag top of et PU tbg & circ well with P&A mud. POOH lay w/tbg & WOC. RIH w/tbg & tag top of cmt/at @ 605'. POOH w/tbg & WOC. CWI & SDFN	ALTERING CASING DE DRILLING OPNS. PAND A X EMENT JOB DE L'AIS, and give pertinent dates, including estimated date ns: Attach wellbore diagram of proposed completion vice; ND wellhead, & NU BOP's. PU & RIH existing CIBP @ 3268'. Mix & Pump 25 sxs plug on ving down tubing to 1300'. Mix & Pump 25 sxs cmt. 1051'. POOH laying down tbg to 605'. Mix & I.
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or complet of starting any proposed work or recompletion. 09/22/2006 - Arrive on loc Hold taw/2-3/8" tubing. SDFN 09/25/2006 - Hold tailgate safety meet Top of CIBP @ 3268'. Plug @ 1300'. POOH Pump a 25 sx cmt plug 09/26/2006 - Hold tailgate safety meet 19/26/2006 - Hold	CHANGE PLANS MULTIPLE COMPL OTHER: eted operations. (Clearly state all pertinent detak). SEE RULE 1103. For Multiple Completion uilgate safety meeting. MIRU Royalty Well Server of Due to high winds. eting, cont to PU & RIH w/tubing. Tag top of eterning and point of the PU they were well with P&A mud. POOH lay w/they & WOC. RIH w/they & tag top of cmt/at @ 605'. POOH w/they & WOC. CWI & SDFN eting, RIH w/they OE and tag top of cmt plug @	ALTERING CASING DE DRILLING OPNS. PAND A X EMENT JOB DE DRILLING OPNS. PU & RIH Existing CIBP @ 3268'. Mix & Pump 25 sxs plug on ring down tubing to 1300'. Mix & Pump 25 sxs cmt. 1051'. POOH laying down tbg to 605'. Mix & I. 288'. POOH laying down tbg to 63'. Mix & circ a
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or complet of starting any proposed work or recompletion. 09/22/2006 – Arrive on loc. – Hold taw/2-3/8" tubing. SDFN 09/25/2006 – Hold tailgate safety meet Top of CIBP @ 3268'. Plug @ 1300'. POOH Pump a 25 sx cmt plug 09/26/2006 – Hold tailgate safety meet 109/26/2006 – H	CHANGE PLANS MULTIPLE COMPL OTHER: eted operations. (Clearly state all pertinent deta- k). SEE RULE 1103. For Multiple Completion nilgate safety meeting. MIRU Royalty Well Serve Due to high winds. eting, cont to PU & RIH w/tubing. Tag top of et PU tbg & circ well with P&A mud. POOH lay w/tbg & WOC. RIH w/tbg & tag top of cmt/at @ 605'. POOH w/tbg & WOC. CWI & SDFN	ALTERING CASING CE DRILLING OPNS. PAND A X EMENT JOB CASING CE DRILLING OPNS. PAND A X EMENT JOB CASING CE DRILLING OPNS. PAND A X EMENT JOB CASING CIBP CONTROL OF THE PROPERTY OF THE PROPER
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or complet of starting any proposed work or recompletion. 09/22/2006 – Arrive on loc. – Hold taw/2-3/8" tubing. SDFN 09/25/2006 – Hold tailgate safety meet Top of CIBP @ 3268'. Plug @ 1300'. POOH Pump a 25 sx cmt plug 09/26/2006 – Hold tailgate safety meet 109/26/2006 – H	CHANGE PLANS MULTIPLE COMPL OTHER: eted operations. (Clearly state all pertinent detak). SEE RULE 1103. For Multiple Completion uilgate safety meeting. MIRU Royalty Well Server of Due to high winds. eting, cont to PU & RIH w/tubing. Tag top of eterning and point of the PU they were well with P&A mud. POOH lay w/they & WOC. RIH w/they & tag top of cmt/at @ 605'. POOH w/they & WOC. CWI & SDFN eting, RIH w/they OE and tag top of cmt plug @	ALTERING CASING CE DRILLING OPNS. PAND A X EMENT JOB CASING CE DRILLING OPNS. PAND A X EMENT JOB CASING CE DRILLING OPNS. PAND A X EMENT JOB CASING CIBP CONTROL OF THE PROPERTY OF THE PROPER
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or complet of starting any proposed work or recompletion. 09/22/2006 – Arrive on loc. – Hold taw/2-3/8" tubing. SDFN 09/25/2006 – Hold tailgate safety meet Top of CIBP @ 3268'. Plug @ 1300'. POOH Pump a 25 sx cmt plug 09/26/2006 – Hold tailgate safety meet 109/26/2006 – H	CHANGE PLANS MULTIPLE COMPL OTHER: eted operations. (Clearly state all pertinent detak). SEE RULE 1103. For Multiple Completion uilgate safety meeting. MIRU Royalty Well Server of Due to high winds. eting, cont to PU & RIH w/tubing. Tag top of eterning and point of the PU they were well with P&A mud. POOH lay w/they & WOC. RIH w/they & tag top of cmt/at @ 605'. POOH w/they & WOC. CWI & SDFN eting, RIH w/they OE and tag top of cmt plug @	ALTERING CASING CE DRILLING OPNS. PAND A X EMENT JOB CASING CE DRILLING OPNS. PAND A X EMENT JOB CASING CE DRILLING OPNS. PAND A X EMENT JOB CASING CIBP CONTROL OF THE PROPERTY OF THE PROPER
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or complet of starting any proposed work or recompletion. 09/22/2006 – Arrive on loc. – Hold taw/2-3/8" tubing. SDFN 09/25/2006 – Hold tailgate safety meet Top of CIBP @ 3268'. Plug @ 1300'. POOH Pump a 25 sx cmt plug 09/26/2006 – Hold tailgate safety meet 109/26/2006 – H	CHANGE PLANS MULTIPLE COMPL OTHER: eted operations. (Clearly state all pertinent detak). SEE RULE 1103. For Multiple Completion uilgate safety meeting. MIRU Royalty Well Server of Due to high winds. eting, cont to PU & RIH w/tubing. Tag top of eterning and point of the PU they were well with P&A mud. POOH lay w/they & WOC. RIH w/they & tag top of cmt/at @ 605'. POOH w/they & WOC. CWI & SDFN eting, RIH w/they OE and tag top of cmt plug @	ALTERING CASING CE DRILLING OPNS. PAND A X EMENT JOB CASING CE DRILLING OPNS. PAND A X EMENT JOB CASING CE DRILLING OPNS. PAND A X EMENT JOB CASING CIBP CONTROL OF THE PROPERTY OF THE PROPER
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or complet of starting any proposed work or recompletion. 09/22/2006 - Arrive on loc Hold taw/2-3/8" tubing. SDFN 09/25/2006 - Hold tailgate safety meet Top of CIBP @ 3268'. Plug @ 1300'. POOH Pump a 25 sx cmt plug 09/26/2006 - Hold tailgate safety meet 19/26/2006 - Hold	CHANGE PLANS MULTIPLE COMPL OTHER: eted operations. (Clearly state all pertinent detak). SEE RULE 1103. For Multiple Completion uilgate safety meeting. MIRU Royalty Well Server of Due to high winds. eting, cont to PU & RIH w/tubing. Tag top of eterning and point of the PU they were well with P&A mud. POOH lay w/they & WOC. RIH w/they & tag top of cmt/at @ 605'. POOH w/they & WOC. CWI & SDFN eting, RIH w/they OE and tag top of cmt plug @	ALTERING CASING DE DRILLING OPNS. PAND A X EMENT JOB DE DRILLING OPNS. PU & RIH Existing CIBP @ 3268'. Mix & Pump 25 sxs plug on ring down tubing to 1300'. Mix & Pump 25 sxs cmt. 1051'. POOH laying down tbg to 605'. Mix & I. 288'. POOH laying down tbg to 63'. Mix & circ a
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or complet of starting any proposed work or recompletion. 09/22/2006 - Arrive on loc Hold taw/2-3/8" tubing. SDFN 09/25/2006 - Hold tailgate safety meet Top of CIBP @ 3268'. Plug @ 1300'. POOH Pump a 25 sx cmt plug 09/26/2006 - Hold tailgate safety meet 19/26/2006 - Hold	CHANGE PLANS MULTIPLE COMPL OTHER: eted operations. (Clearly state all pertinent detak). SEE RULE 1103. For Multiple Completion uilgate safety meeting. MIRU Royalty Well Server of Due to high winds. eting, cont to PU & RIH w/tubing. Tag top of eterning and point of the PU they were well with P&A mud. POOH lay w/they & WOC. RIH w/they & tag top of cmt/at @ 605'. POOH w/they & WOC. CWI & SDFN eting, RIH w/they OE and tag top of cmt plug @	ALTERING CASING DE DRILLING OPNS. PAND A X EMENT JOB DE DRILLING OPNS. PU & RIH Existing CIBP @ 3268'. Mix & Pump 25 sxs plug on ring down tubing to 1300'. Mix & Pump 25 sxs cmt. 1051'. POOH laying down tbg to 605'. Mix & I. 288'. POOH laying down tbg to 63'. Mix & circ a
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or comple of starting any proposed wor or recompletion. 09/22/2006 – Arrive on loc. – Hold ta w/2-3/8" tubing. SDFN 09/25/2006 – Hold tailgate safety mee Top of CIBP @ 3268'. Plug @ 1300'. POOH Pump a 25 sx cmt plug 09/26/2006 – Hold tailgate safety mee 10 sx cmt plug @ 63' baren 10 sx cmt plug @ 63' b	CHANGE PLANS MULTIPLE COMPL OTHER: eted operations. (Clearly state all pertinent deta- k). SEE RULE 1103. For Multiple Completion milgate safety meeting. MIRU Royalty Well Server Due to high winds. eting, cont to PU & RIH w/tubing. Tag top of er PU tbg & circ well with P&A mud. POOH lay w/tbg & WOC. RIH w/tbg & tag top of cmt/at @ 605'. POOH w/tbg & WOC. CWI & SDFN eting, RIH w/tbg OE and tag top of cmt plug @ ack to surface. RDMO. Dig out & cut off wellf	ALTERING CASING CE DRILLING OPNS. PAND A X EMENT JOB CASING CE DRILLING OPNS. PAND A X EMENT JOB CASING CIIS, and give pertinent dates, including estimated date ins: Attach wellbore diagram of proposed completion vice; ND wellhead, & NU BOP's. PU & RIH existing CIBP @ 3268'. Mix & Pump 25 sxs plug on ring down tubing to 1300'. Mix & Pump 25 sxs cmt. 1051'. POOH laying down tbg to 605'. Mix & I. 288'. POOH laying down tbg to 63'. Mix & circ a nead 3' B.G. L. & weld on dry hole marker.
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or complet of starting any proposed work or recompletion. 09/22/2006 – Arrive on loc. – Hold taken w/2-3/8" tubing. SDFN 09/25/2006 – Hold tailgate safety meet Top of CIBP @ 3268'. Plug @ 1300'. POOH Pump a 25 sx cmt plug 09/26/2006 – Hold tailgate safety meet 10 sx cmt plug @ 63' base of the	CHANGE PLANS MULTIPLE COMPL OTHER: eted operations. (Clearly state all pertinent detak). SEE RULE 1103. For Multiple Completion milgate safety meeting. MIRU Royalty Well Server I Due to high winds. eting, cont to PU & RIH w/tubing. Tag top of ere PU tbg & circ well with P&A mud. POOH lay w/tbg & WOC. RIH w/tbg & tag top of cmt/at @ 605'. POOH w/tbg & WOC. CWI & SDFN eting, RIH w/tbg OE and tag top of cmt plug @ ack to surface. RDMO. Dig out & cut off wellf above is true and complete to the best of my known.	ALTERING CASING CE DRILLING OPNS. PAND A X EMENT JOB CASING CE DRILLING OPNS. PAND A X EMENT JOB CASING CE DRILLING OPNS. PAND A X EMENT JOB CASING CIBP CONTROL OF THE PROPERTY OF THE PROPER
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or complet of starting any proposed work or recompletion. 09/22/2006 – Arrive on loc. – Hold taken w/2-3/8" tubing. SDFN 09/25/2006 – Hold tailgate safety meet Top of CIBP @ 3268'. Plug @ 1300'. POOH Pump a 25 sx cmt plug 09/26/2006 – Hold tailgate safety meet 10 sx cmt plug @ 63' base of the	CHANGE PLANS MULTIPLE COMPL OTHER: eted operations. (Clearly state all pertinent deta ck). SEE RULE 1103. For Multiple Completion uilgate safety meeting. MIRU Royalty Well Serve Due to high winds. eting, cont to PU & RIH w/tubing. Tag top of e PU tbg & circ well with P&A mud. POOH lay w/tbg & WOC. RIH w/tbg & tag top of cmt/at @ 605'. POOH w/tbg & WOC. CWI & SDFN eting, RIH w/tbg OE and tag top of cmt plug @ ack to surface. RDMO. Dig out & cut off wellf closed according to NMOCD guidelines , a general per	ALTERING CASING CE DRILLING OPNS. PAND A X EMENT JOB CASING CE DRILLING OPNS. PAND A X EMENT JOB CASING CAS
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or complet of starting any proposed work or recompletion. 09/22/2006 – Arrive on loc. – Hold taken w/2-3/8" tubing. SDFN 09/25/2006 – Hold tailgate safety meet Top of CIBP @ 3268'. Plug @ 1300'. POOH Pump a 25 sx cmt plug 09/26/2006 – Hold tailgate safety meet 10 sx cmt plug @ 63' base of the	CHANGE PLANS MULTIPLE COMPL OTHER: eted operations. (Clearly state all pertinent deta ck). SEE RULE 1103. For Multiple Completion uilgate safety meeting. MIRU Royalty Well Serve Due to high winds. eting, cont to PU & RIH w/tubing. Tag top of e PU tbg & circ well with P&A mud. POOH lay w/tbg & WOC. RIH w/tbg & tag top of cmt/at @ 605'. POOH w/tbg & WOC. CWI & SDFN eting, RIH w/tbg OE and tag top of cmt plug @ ack to surface. RDMO. Dig out & cut off wellf closed according to NMOCD guidelines , a general per	ALTERING CASING CE DRILLING OPNS. PAND A X EMENT JOB CASING CE DRILLING OPNS. PAND A X EMENT JOB CASING CAS
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or complet of starting any proposed work or recompletion. 09/22/2006 – Arrive on loc. – Hold taken w/2-3/8" tubing. SDFN 09/25/2006 – Hold tailgate safety meet Top of CIBP @ 3268'. Plug @ 1300'. POOH Pump a 25 sx cmt plug 09/26/2006 – Hold tailgate safety meet 10 sx cmt plug @ 63' base of the	CHANGE PLANS MULTIPLE COMPL OTHER: eted operations. (Clearly state all pertinent detak). SEE RULE 1103. For Multiple Completion milgate safety meeting. MIRU Royalty Well Server I Due to high winds. eting, cont to PU & RIH w/tubing. Tag top of ere PU tbg & circ well with P&A mud. POOH lay w/tbg & WOC. RIH w/tbg & tag top of cmt/at @ 605'. POOH w/tbg & WOC. CWI & SDFN eting, RIH w/tbg OE and tag top of cmt plug @ ack to surface. RDMO. Dig out & cut off wellf above is true and complete to the best of my known.	ALTERING CASING CE DRILLING OPNS. PAND A X EMENT JOB CASING CE DRILLING OPNS. PAND A X EMENT JOB CASING CAS
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or complet of starting any proposed work or recompletion. 09/22/2006 - Arrive on loc Hold taken w/2-3/8" tubing. SDFN 09/25/2006 - Hold tailgate safety meet Top of CIBP @ 3268'. Plug @ 1300'. POOH Pump a 25 sx cmt plug 09/26/2006 - Hold tailgate safety meet 10 sx cmt plug @ 63' but the safety meet 10 sx cmt	CHANGE PLANS MULTIPLE COMPL OTHER: eted operations. (Clearly state all pertinent deta k). SEE RULE 1103. For Multiple Completion milgate safety meeting. MIRU Royalty Well Server Due to high winds. eting, cont to PU & RIH w/tubing. Tag top of e PU tbg & circ well with P&A mud. POOH lay w/tbg & WOC. RIH w/tbg & tag top of cmt/at @ 605'. POOH w/tbg & WOC. CWI & SDFN eting, RIH w/tbg OE and tag top of cmt plug @ ack to surface. RDMO. Dig out & cut off wellf blove is true and complete to the best of my known of the surface of the surface. TITLE Sr. Regulatory E-mail address:	ALTERING CASING CE DRILLING OPNS. PAND A X EMENT JOB CASING CE DRILLING OPNS. PAND A X EMENT JOB CASING CAS
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or complet of starting any proposed work or recompletion. 09/22/2006 - Arrive on loc Hold taken w/2-3/8" tubing. SDFN 09/25/2006 - Hold tailgate safety meet Top of CIBP @ 3268'. Plug @ 1300'. POOH Pump a 25 sx cmt plug 09/26/2006 - Hold tailgate safety meet 10 sx cmt plug @ 63' but the safety meet 10 sx c	CHANGE PLANS MULTIPLE COMPL OTHER: eted operations. (Clearly state all pertinent deta k). SEE RULE 1103. For Multiple Completion milgate safety meeting. MIRU Royalty Well Server Due to high winds. eting, cont to PU & RIH w/tubing. Tag top of e PU tbg & circ well with P&A mud. POOH lay w/tbg & WOC. RIH w/tbg & tag top of cmt/at @ 605'. POOH w/tbg & WOC. CWI & SDFN eting, RIH w/tbg OE and tag top of cmt plug @ ack to surface. RDMO. Dig out & cut off wellf blove is true and complete to the best of my known of the surface of the surface. TITLE Sr. Regulatory E-mail address:	Anaylst
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or comple of starting any proposed wor or recompletion. 09/22/2006 - Arrive on loc Hold taw/2-3/8" tubing. SDFN 09/25/2006 - Hold tailgate safety med Top of CIBP @ 3268'. Plug @ 1300'. POOH Pump a 25 sx cmt plug 09/26/2006 - Hold tailgate safety med 10 sx cmt plug @ 63' but hereby certify that the information a grade tank has been/will be constructed or c	CHANGE PLANS MULTIPLE COMPL OTHER: eted operations. (Clearly state all pertinent detak). SEE RULE 1103. For Multiple Completion milgate safety meeting. MIRU Royalty Well Server Due to high winds. eting, cont to PU & RIH w/tubing. Tag top of exputing a circ well with P&A mud. POOH lay w/tbg & WOC. RIH w/tbg & tag top of cmt/at (@ 605'. POOH w/tbg & WOC. CWI & SDFN eting, RIH w/tbg OE and tag top of cmt plug @ ack to surface. RDMO. Dig out & cut off wellf a closed according to NMOCD guidelines , a general per closed according to NMOCD guidelines , a general per closed according to NMOCD guidelines , a general per closed according to NMOCD guidelines , a general per closed according to NMOCD guidelines , a general per closed according to NMOCD guidelines , a general per closed according to NMOCD guidelines , a general per closed according to NMOCD guidelines , a general per closed according to NMOCD guidelines , a general per closed according to NMOCD guidelines .	ALTERING CASING CE DRILLING OPNS. PAND A X EMENT JOB CASING CE DRILLING OPNS. PAND A X EMENT JOB CASING CE DRILLING OPNS. PAND A X EMENT JOB CASING CIBP CONTROL OF THE PAND A X EMENT JOB CASING CIBP CONTROL OF THE PAND A X EMENT JOB CASING CIBP CONTROL OF THE PAND A X EMENT JOB CASING CIBP CONTROL OF THE PAND A X EMENT JOB CASING
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or complet of starting any proposed work or recompletion. 09/22/2006 - Arrive on loc Hold taken w/2-3/8" tubing. SDFN 09/25/2006 - Hold tailgate safety meet Top of CIBP @ 3268'. Plug @ 1300'. POOH Pump a 25 sx cmt plug 09/26/2006 - Hold tailgate safety meet 10 sx cmt plug @ 63' but the safety meet 10 sx cmt	CHANGE PLANS MULTIPLE COMPL OTHER: eted operations. (Clearly state all pertinent deta k). SEE RULE 1103. For Multiple Completion milgate safety meeting. MIRU Royalty Well Server Due to high winds. eting, cont to PU & RIH w/tubing. Tag top of e PU tbg & circ well with P&A mud. POOH lay w/tbg & WOC. RIH w/tbg & tag top of cmt/at @ 605'. POOH w/tbg & WOC. CWI & SDFN eting, RIH w/tbg OE and tag top of cmt plug @ ack to surface. RDMO. Dig out & cut off wellf blove is true and complete to the best of my known of the surface of the surface. TITLE Sr. Regulatory E-mail address:	ALTERING CASING CE DRILLING OPNS. PAND A X EMENT JOB CASING CE DRILLING OPNS. PAND A X EMENT JOB CASING CE DRILLING OPNS. PAND A X EMENT JOB CASING CIBP CONTROL OF THE PAND A X EMENT JOB CASING CIBP CONTROL OF THE PAND A X EMENT JOB CASING CIBP CONTROL OF THE PAND A X EMENT JOB CASING CIBP CONTROL OF THE PAND A X EMENT JOB CASING