STATE OF NEW MEXICO JERGY AND MINERALS DEPARTMENT

NO. OF COPIES SCCEIVED	T	
DISTRIBUTION		
SANTA FE		
TILE		
U.\$.G.\$,		
LAND OFFICE		
OPERATOR		

OIL CONSERVATION DIVISION

1983

DATE JUN A

DISTRIBUTION	P. O. BO	X 2088	Form C-103	
SANTA FE	SANTA FE, NEW	MEXICO 87501	Revised 10-1-78	
/ILE	5,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,		5a. Indicate Type of Lease	
U.\$.O.\$,				
LAND OFFICE				
OPERATOR			5. State Oil & Gas Lease No.	
SUMPRY	NOTICES AND REPORTS ON	WELLS		
I AUPIUC 00099 ROT MROT CINT DEU TON 00) 1017ADIJ994** DEU	SSALS TO DAILL OR TO DEEPEN OR PLUG B	ACK TO A DIFFERENT RESERVOIR.		
USE	TPDR PERMIT = 17 ORM C-7017 FOR SOC	7,0,03,00,7	7. Unit Agreement Name	
OIL X GAB WELL				
	OTHER-		8. Farm or Lease Name	
. Name of Operator				
Tom R. Minihan			Santa Fe "D"	
, Address of Operator			1	
P.O. Box 4364	P.O. Box 4364 Midland, TX. 79704		1	
ocation of Well		10. Field and Pool, or Wildcat		
UNIT LETTER C 660 FEET FROM THE NOTTH LINE AND FEET FROM		Crossroad Penn		
UNIT LETTER C	PEET PROM THE			
at	20 9 9	36 F		
THE WEST LINE, SECTION	TOWNSHIP 7 L	RANGE 36 E NMPN		
mmmmm.	7777 St (\$1	DE PT CP 410 1	12. County	
	15. Elevation (Show whether	Dr, RI, GR, etc.)	12. Comity	
	N/A		Lea (\\\\\\\\	
Check At	opropriate Box To Indicate N	ature of Notice, Report or O	ther Data	
* * *			T REPORT OF:	
NOTICE OF INT				
	PLUG AND ABANDON	REMEDIAL WORK	ALTERING CASING	
PERFORM REMEDIAL WORK	PLUC AND ABANDON		PLUG AND ABANDONMENT	
TEMPORARILY ABAHOON		COMMENCE DRILLING OPNS.	PEDE AND ABANDONMENT	
PULL OR ALTER CABING	CHANGE PLANS	CASING TEST AND CEMENT JQB		
	16 6 -11	OTHER		
OTHER Perforate & test Wo	olicams formation X			
		il and it a series and date it all dis	a actimated date of starting any proposed	
Describe Proposed or Completed Oper work) SEE RULE 1103.	rations (Clearly state all pertinent det	ails, and give pertinent dates, includin	g estimated date of starting any proposed	
WORKY SEE HOLE 1103.				
While weiting on approx	val to perform work over	r indicated below we wil	1 continue testing	
		indicated below we wil	1 continue testing	
well and monitoring flu	iid level.			
 MIRU service unit. 	Pull rods & tubing.			
2. Set CIBP at 9500' a	and dump 2 sx cement on	top of CIBP.		
3. Perforate Wolfcamp	9186' - 9200'.			
1				
4. Acidize & swab test				
4. Relaize a swab cese	•			
E Down tubing and roa	ds. Pump test Wolfcamp			
5. Refun tubing and for	15. Fump test wolfcamp	•		
	•			
	•			
<u></u>				
2. I hereby certify that the information a	bove is true and complete to the best	of my knowledge and belief.		
1 i(-121 -	01	vner & Operator	DATE 6/2/83	
1. NIO / 16 LUL / L - 1-1-1-1	TITLE			

ORIGINAL SIGNED BY JERRY SEXTON

DISTRICT I SUPERVISOR