

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
E-8835	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator		8. Farm or Lease Name
TEXACO Inc.		New Mexico "CQ" State
3. Address of Operator		9. Well No.
P. O. Box 728, Hobbs, New Mexico 88240		1
4. Location of Well		10. Field and Pool, or Wildcat
UNIT LETTER <u>K</u> , <u>1980</u> FEET FROM THE <u>South</u> LINE AND <u>1980</u> FEET FROM		Inbe Permo Penn
THE <u>West</u> LINE, SECTION <u>35</u> TOWNSHIP <u>10-S</u> RANGE <u>33-E</u> NMPM.		
15. Elevation (Show whether DF, RT, GR, etc.)		12. County
4199' DF		Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data			
NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

The following work on subject well has been completed:

1. Spot 100 sx cement plug 7300' - 9600'.
2. Shot 2 7/8" tubing off @ 4679'.
3. Spot 25 sx cement plug @ 4679'. Tagged plug @ 4104'.
4. Spot 50 sx cement plug @ 4104' - 3544'.
5. Shot off 2 7/8" tubing @ 2600' and pulled.
6. Spot 50 sx cement plug @ 2600' - 2100'.
7. Spot 10 sx cement plug @ surface.
8. Installed 4" dry hole marker extending 4' above ground level.
9. Clean location. Plug and abandon.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Jalchuff</u>	TITLE <u>Assistant District Superintendent</u>	DATE <u>July 9, 1971</u>
APPROVED BY <u>Nathan E. Oleg</u>	TITLE <u>OIL & GAS INSPECTOR</u>	DATE <u>DEC 22 1971</u>
CONDITIONS OF APPROVAL, IF ANY:		

RECEIVED

JUL 12 1971

OIL CONSERVATION COMM.
HOBBS, N. M.