

STATE OF NEW MEXICO  
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. V-1366

SUNDRY NOTICES AND REPORTS ON WELLS

DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.

OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- P&A		7. Unit Agreement Name
Name of Operator Yates Petroleum Corporation		8. Farm or Lease Name Carper McAlester ACX St.
Address of Operator 207 South 4th St., Artesia, NM 88210		9. Well No. 1
Location of Well UNIT LETTER C 660 FEET FROM THE North LINE AND 1650 FEET FROM THE West LINE, SECTION 25 TOWNSHIP 11S RANGE 34E NMPM.		10. Field and Pool, or wildcat Eight Mile Draw Permo Penn
11. Elevation (Show whether DF, RT, GR, etc.) 4144' GR		12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

7. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Verbal permisison obtained 9-3-85 from Mr. Jerry Sexton, NMOCD, Hobbs, by Mr. Ray Stall, YPC, to plug well as follows:

- 1) Spot and tag 300' plug from top of fish at 5801' back up to 5500'.  
Plug must be tagged @5500'.
- 2) Spot and tag 100' plug from 4125-4025' (50' in and out of 9-5/8" casing shoe).  
Plug must be tagged.
- 3) Spot 100' plug across 9-5/8" x 8-5/8" casing splice from 1250' back up to 1150'.
- 4) Spot 100' plug inside 8-5/8" casing across 13-3/8" casing shoe depth from 407' back up to 307'.
- 5) Set 15 sack plug at surface and install regulation abandonment marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Jerry Sexton TITLE Production Supervisor DATE 9-5-85  
ORIGINAL SIGNED BY JERRY SEXTON  
DISTRICT SUPERVISOR

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE SEP - 9 1985  
CONDITIONS OF APPROVAL, IF ANY: