

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-85

5a. Indicate Type of Lease
State ☒ Fee ☐

5. State Oil & Gas Lease No.

06-5084

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐	7. Unit Agreement Name
2. Name of Operator CONOCO INC.	8. Form or Lease Name State II-23
3. Address of Operator P. O. Box 460, Hobbs, N.M. 88240	9. Well No. 2
4. Location of Well UNIT LETTER <u>E</u> <u>1980</u> FEET FROM THE <u>North</u> LINE AND <u>660</u> FEET FROM THE <u>West</u> LINE, SECTION <u>23</u> TOWNSHIP <u>10S</u> RANGE <u>32E</u> N.M.P.M.	10. Field and Pool, or Wildcat Mescalero San Andres
15. Elevation (Show whether DF, RT, GR, etc.)	12. County Lea

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐
OTHER repair surface waterflow ☒

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOBS ☐
OTHER ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- ① MIRU. POOH w/ rods & pump. Run scraper to 4060'. Set RBP @ 4050'.
- ② Spot 2sxs sand on RBP. Establish pump-in rate @ bradenhead valve.
- ③ Run tracer survey. Bradenhead sqz w/ 2bbls salt saturated brine, 2 bbls fresh wtr spacer, 20 bbls Flo-Check & tail-in w/ 240 sxs class "H" w/ 2% CaCl₂. Displace cmt thro wellhead w/ fresh wtr, shut-in bradenhead valve & install popoff valve set @ 800 psi. Rel RBP, hang well on & rig down.
- ④ If unable to establish pump-in rate, Perf @ 1477'. Set pkr @ 1377'. POOH w/ pkr & set cmt retainer @ 1377'. Pump 360 sxs class "H" w/ 2% CaCl₂.
- ⑤ Once good returns are seen @ surface, shut-in bradenhead valve. Tag TOC & drill out. Press. test sqz perms to 500psi. Rel RBP & POOH.
- ⑥ Hang well on & rig down.

THE COMMISSION MUST BE NOTIFIED
24 HOURS PRIOR TO COMMENCING WORK

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Jerry Sexton TITLE Administrative Supervisor DATE 10-13-86

ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT 1 SUPERVISOR

APPROVED BY _____ TITLE _____ DATE OCT 15 1986
CONDITIONS OF APPROVAL, IF ANY: NMOC-D-Hobbs(3)
File