

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Aug 13 11 1967

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>	
5. State Oil & Gas Lease No. <b>K-1616</b>	
7. Unit Agreement Name	
8. Farm or Lease Name <b>Cities Service State</b>	
9. Well No. <b>1</b>	
10. Field and Pool, or Wildcat <b>Wildcat</b>	
12. County <b>Lea</b>	

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <b>New Well</b>	
2. Name of Operator <b>Cities Service Oil Company</b>	
3. Address of Operator <b>Box 69, Hobbs, New Mexico</b>	
4. Location of Well UNIT LETTER <b>P</b> , <b>660</b> FEET FROM THE <b>South</b> LINE AND <b>660</b> FEET FROM THE <b>East</b> LINE, SECTION <b>20</b> TOWNSHIP <b>11S</b> RANGE <b>38E</b> NMPM.	
15. Elevation (Show whether DF, RT, GR, etc.) <b>3893 Gr. Est.</b>	


16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> OTHER <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/> CHANGE PLANS <input type="checkbox"/> REMEDIAL WORK <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> CASING TEST AND CEMENT JOBS <input type="checkbox"/> OTHER <input type="checkbox"/>
ALTERING CASING <input type="checkbox"/> PLUG AND ABANDONMENT <input checked="" type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

The above well was plugged and abandoned in the following manner:

1. Loaded hole with mud laden fluid.
2. Set 25 sack cement plug across perfs. (5209-5152)
3. Cut and pulled 5½" casing @ 3448. Set 25 sack cement plug 3498-3398 (½ in and ½ out of casing stub).
4. Cut and pulled 8 5/8" casing @ 1332. Set 25 sack cement plug @ 1372-1292 (½ in and ½ out of casing stub).
5. Set 10 sack cement surface plug @ 30' - 0' w/4" marker extending 4' above ground to designate P & A location.
6. Cleaned location of all equipment and debris, filled pits and cellar.
7. Location is now ready for inspection.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED 	TITLE <b>District Superintendent</b>	DATE <b>8/3/67</b>
APPROVED BY	TITLE	DATE
CONDITIONS OF APPROVAL, IF ANY:		