

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator <b>Sun Oil Company</b>		8. Name of Leaseholder <b>New Mexico "I" State</b>
3. Address of Operator <b>P. O. Box 2792, Odessa, Texas 79760</b>		9. Well No. <b>1</b>
4. Location of Well UNIT LETTER <b>B</b> <b>660</b> FEET FROM THE <b>North</b> LINE AND <b>1978.9</b> FEET FROM THE <b>East</b> LINE, SECTION <b>7</b> TOWNSHIP <b>11 S</b> RANGE <b>34 E</b> NMPM		10. Field and Pool, or Wildcat <b>Inbe Penn</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>4198 Gr.</b>		12. County <b>Lea</b>

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐  
TEMPORARILY ABANDON ☐  
PULL OR ALTER CASING ☐  
OTHER ☐

PLUG AND ABANDON ☒  
CHANGE PLANS ☐  
OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐  
COMMENCE DRILLING OPNS. ☐  
CASING TEST AND CEMENT JOBS ☐  
OTHER ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Move in casing pullers. Run CIBP set at appx. 8500'. Run free point on 4 1/2" csg., shoot csg. appx. 5000'. Pull and recover 4 1/2" casing. Run 2" tubing, spot 25 sk cement plug across 4 1/2" casing stub. Raise 2" tbg to 8 5/8" csg seat @ 4000'. Spot 50 sk cement plug across 8 5/8" casing seat. Pull 2" tubing, run free point on 8 5/8" casing - shoot 8 5/8" csg. appx. 2500'. Pull and recover 8 5/8" casing - appx. 2500'. Run 2" tbg., spot 25 sk cement plug across 8 5/8" casing stub. Raise 2" tubing, spot 10 sk cement plug at surface, install permanent marker.

Note, Plugging procedure approved by Joe Ramey w/NMOCC.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>John M. Sweeney</u>	TITLE <u>Asst Dist. Superintendent</u>	DATE <u>3-10-70</u>
APPROVED BY <u>[Signature]</u>	TITLE _____	DATE _____
CONDITIONS OF APPROVAL, IF ANY:		