

COPIES RECEIVED	
TRIBUTION	
FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State Fee
5. State Oil & Gas Lease No.
K-4338

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL GAS WELL OTHER Dry Hole
2. Name of Operator
Coquina Oil Corporation
3. Address of Operator
200 Building of the Southwest, Midland, Texas 79701
4. Location of Well
UNIT LETTER I 510 FEET FROM THE E LINE AND 1980 FEET FROM THE S LINE, SECTION 27 TOWNSHIP 14S RANGE 34E NMPM.
7. Unit Agreement Name
8. Farm or Lease Name
Cities Service State
9. Well No.
#3
10. Field and Pool, or Wildcat
Undesignated
15. Elevation (Show whether DF, RT, GR, etc.)
4086' G. L.
12. County
Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

It is proposed to plug & abandon the subject well as follows:

1. Set CIBP @ approx 9950'. Dump ^{35'} cement on top of CIBP.
2. Run free point & pull approx 5600' 5 1/2" casing.
3. Cut 8 5/8" Intermediate csg at approx 1300'.
4. Spot 50 sx plug from 5700' to 5600'.
5. Spot 50 sx plug from 4600'-4500' (8 5/8" Int. csg shoe @ 4553').
6. Spot 50 sx plug across 8 5/8" stub.
7. Spot 50 sx plug from 400' to 300'. (12 3/4" surface csg shoe @ 353').
8. Spot 10 sx surface plug.
9. Install Dry Hole Marker.

Hole to be filled with mud laden fluid.

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE C-103 TO BE APPROVED.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED D. C. Radtke (D. C. Radtke) TITLE Engineer DATE 6-27-74

APPROVED BY Joe D. Ramey Dist. I, Supv. TITLE SUPERVISOR DISTRICT I DATE JUN 28 1974

CONDITIONS OF APPROVAL, IF ANY: