

- E. Cut off dead-man anchors below ground level and remove markers. Fill in cellar and workover pit.
 - F. Remove all equipment, concrete bases, and pipe not in use.
 - G. Clean and restore location to its natural state. Reseed according to BLM requirements.
6. Send a copy of the well service report to Kandy Lawson in the Hobbs Office so the proper forms can be filed.

Approved:

Tom C. Geddudell
Engineering Technician

10-20-89
Date

Jay Vaskler
Engineer

10-23-89
Date

Bill C. Porter
Supervising Production Engineer

10/30/89
Date

Michael L. Morrison
Division Engineering Manager

10-31-89
Date

Carl M. Vignone
Production Superintendent

11/3/89
Date

TCA:mjm
MB23NO5.PRO