

MUD PROGRAM

<u>DEPTH INTERVAL</u> <u>FT(X)-TO</u>	<u>WEIGHT</u> <u>LBS/CAL</u>	<u>TYPE</u>	<u>OIL %</u>	<u>pH</u>	<u>WATER LOSS</u> <u>(cc)</u>	<u>VIS. (sec.)</u>	<u>YIELD</u> <u>POINT</u>	<u>THINNING</u> <u>AGENTS</u>	<u>WATER LOSS</u> <u>AGENTS</u>
0'-1450'	8.5-9.0	Spud	--	9.0+	--				As required
1450'-6835'	9.0-10.0	Salt Water Gel	--	9.0-10.0	10-12+	35-40			As required

REMARKS

- (1) Below 1450', drill w/saturated brine to keep hole enlargement to a minimum.
- (2) Add gelling agent as required to carry cuttings.
- (3) Pressure surges should be kept to a minimum below 1450'.
- (4) Condition mud to reduce water loss 50' above Blinebry Marker.
- (5) Condition mud to reduce viscosity prior to pumping cement.