

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease  
State  Fee

5. State Oil & Gas Lease No.  
**E 7825**

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator <b>Paul E. Plummer &amp; W. H. McKinley</b>	8. Farm or Lease Name <b>Sinclair St.</b>
3. Address of Operator <b>% Hobbs Pipe &amp; Supply, Box 2010, Hobbs, N.M.</b>	9. Well No. <b>1</b>
4. Location of Well UNIT LETTER <b>R</b> <b>1650</b> FEET FROM THE <b>South</b> LINE AND <b>1650</b> FEET FROM THE <b>East</b> LINE, SECTION <b>2</b> TOWNSHIP <b>21-S</b> RANGE <b>33-E</b> NMPM.	10. Field and Pool, or Wildcat <b>Lynch 7 Rivers</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>DF 3798</b>	12. County <b>Lea</b>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO:      SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to plug and abandon as follows:

1. Spot a 25 sack cement plug at 3850'.
2. Load hole with mud laden fluid.
3. Spot a 25 sack cement plug at stub of 4 1/2" casing.
4. Spot a 25 sack cement plug at top of salt 1765'.
5. Spot a 25 sack cement plug at the bottom of 10 3/4" casing @ 260'.
6. Spot a 10 sack cement plug at surface & erect a marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Agent DATE 10-7-69

APPROVED BY [Signature] TITLE SUPV DATE OCT 10 1969

CONDITIONS OF APPROVAL, IF ANY: