

**ATTACHMENT TO FORM C-105
COLLINS & WARE, INC.
CORRIGAN, H. #7**

27. Treatment Record.

7580	Set CIBP at 7580' and dumped 35' cement on top. (3/75)
5993 - 6269	AT w/3500 gals 15% NE acid.
5993 - 6269	FT w/30,000 gals Ultra-Frac 15 using 42,000# 20/40 sand.
5975	Set retainer at 5975'. Squeeze perms with 200 sx cement. (9/96)
5490 - 5916	AT w/4000 gals 15% Ferchek SC acid.
5490 - 5916	FT w/119,000 gals Delta Frac 25 carrying 310,000# of 16/30 sand. (9/96)