Submit 3 Copies To Appropriate District Office	State of New Mexico Luergy, Minerals and Natural Resources		Form C-103 Revised March 25, 1999	
1625 N. French Dr., Hobbs, NM 87240			WELL API NO.	
District II 811 South First, Artesia, NM 87210 OIL CONSERVATION DIVISION			30-025-22797  5. Indicate Type of Lease	
District III 2040 South Pacheco			STATE FEE	
District IV 2040 South Pacheco, Santa Fe, NM 87505			6. State Oil & Gas Lease No.	
SUNDRY NOTICES AND REPORTS ON WELLS			7. Lease Name or	TT-:A A
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)  1. Type of Well:			Lease Name or Unit Agreement     Name:     BLINEBRY-DRINKARD	
Oil Well Gas Well Other SWD Well				
2. Name of Operator			8. Well No.	25
RICE OPERATING COMPANY  3. Address of Operator			9. Pool name of W	P-35 Vildcat
122 W. TAYLOR, HOBBS, NM 88240			SAN ANDRES	
4. Well Location				
Unit LetterH:_	1872feet from theNORT	H line and233	feet from t	he EASTline
Section 35	Township 22S	Range 37E	NMPM LE	EA County
	10. Elevation (Show whether D. 3293' GL	R, RKB, RT, GR, etc	.)	
11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data				
NOTICE OF INTENTION TO: SUBS			SEQUENT REP	
PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK			<	ALTERING CASING
TEMPORARILY ABANDON	CHANGE PLANS	COMMENCE DRII		PLUG AND ABANDONMENT
	MULTIPLE   COMPLETION	CASING TEST / CEMENT JOB		
OTHER:		OTHER:		
12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation.				
DISTALL INJECTION DACKED DUDGLIANT TO NATUGUETTED 12 01 00. CENEDIC DECEDURE ATTACHED				
INSTALL INJECTION PACKER PURSUANT TO NM UIC LETTER 12-01-99: GENERIC PROCEDURE ATTACHED				
I hereby certify that the information above is true and complete to the best of my knowledge and belief.				
SIGNATURE landyn Levan Hugues TITLE OPERATIONS ENGINEER DATE 4-17-00				
Type or print name CAROLYN DOI				o. 505-393-9174
(This space for State use)	WINTINES		r cicpnone 140	U. 202-272-7114
•	•			· ·
APPPROVED BY Conditions of approval, if any:	TITLE			DATE

UIC Order Generic Procedure April 3, 2000 Page 3 of 3

## RICE OPERATING COMPANY GENERIC PROCEDURE FOR SWD WELLS INSTALL IPC TUBING AND PACKERS

- 1. Prepare location for pulling unit: anchors, base, etc. Bleed-off well if pressurized.
- 2. Move in and rig up on location with pulling unit. Nipple-down wellhead and nipple-up BOP. Plumb back-flow line to tank if necessary. Set 2 7/8" work string on pipe racks.
- 3. Trip out of hole with injection string laying down on pipe racks. For Duoline tubing, have Rice Duoline representative on location. Record static fluid level.
- 4. Pick up mill tooth bit on work string and trip in hole. Tag for fill. Go in hole with casing scraper if necessary. POOH.
- 5. Rig up wire line (Computalog) and log well, especially in area to set packer.
- 6. Go in hole with Packer and Plug to check casing integrity. Repair casing as necessary.
- 7. Rig up pipe testers and go in hole with injection packer on injection string. Pump packer fluid and set packer within 100' of injection interval.
- 8. Nipple down BOP and nipple up well head. Finish filling casing annulus with packer fluid and prepare for MIT testing.
- 9. Perform MIT. Rig pulling unit down. Clean-up location.

NMOCD, Hobbs Office, will be notified 24 hours in advance of MIT.

