

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

RECEIVED

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: September 30, 1990

Dec 20 10 48 AM '90

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.

5. Lease Designation and Serial No.

LC 030168 B

6. If Indian, Allottee or Tribe Name

SUBMIT IN TRIPLICATE

7. If Unit or CA, Agreement Designation

1. Type of Well

Oil Well Gas Well Other

2. Name of Operator

ELK Energy Corporation

3. Address and Telephone No.

1625 Larimer ST, Suite 2403, Denver, Colorado 80202

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

1980 FNC # 660 FWC

Section 30 T26S R37E

10. Field and Pool, or Exploratory Area

Scarborough, Galen-7 Rivers

11. County or Parish, State

Lea, New Mexico

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

Notice of Intent
 Subsequent Report
 Final Abandonment Notice

TYPE OF ACTION

Abandonment
 Recompletion
 Plugging Back
 Casing Repair
 Altering Casing
 Other

Change of Wells
 New Construction
 Non-Routing Fracturing
 Water Shut-Off
 Conversion to Injection

(Note: Report results of multiple completions in Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is functionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Work to clean out, acidize, perform scale inhibitor

12/3-4/90:

1. MI & RU Service R. 9
2. TOOH with rods & pump. Toq bottem with Tubing & tally out. Found NO fill.
3. TIH with tbq + scraper & bit. Ran to PBTP. TOOH up tbq + Tools.
4. TIH up tbq + PPI tool & acidize each perforation, using 1500 gallons 15% acid.
5. Syrb & clean up
6. Perform scale inhibitor squeeze, using 110 gallons of chemical & let set 24 hours. TOOH up tbq + P.P.I. Tool.
7. TIH up tbq, pump & rods & place on Pump. Now pumping.

14. I hereby certify that the foregoing is true and correct

Signed [Signature]

Title U-P Operations

Date 12-14-90

(This space for Federal or State office use)

Approved by _____

Title _____

Date _____

Conditions of approval, if any:

RECEIVED

JAN 09 1997

RECEIVED