

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

P.O. BOX 1980
HOLM, NEW MEXICO 88240

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

5. Lease Designation and Serial No.

NM-2593

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Ed Powell IG Federal #1

9. API Well No.

30-025-25583

10. Field and Pool, or Exploratory Area

Leonard Queen South

11. County or Parish, State

Lea Co., NM

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

YATES PETROLEUM CORPORATION (505) 748-1471

3. Address and Telephone No.

105 South 4th St., Artesia, NM 88210

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

1650' FSL & 330' FWL of Section 18-T26S-R38E (NWSW, Unit L)

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other _____
- ☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Procedure for plug and abandonment was approved by Shannon Shaw with the BLM on April 6, 1994. Propose to plug and abandon as follows:

1. Move in and rig up. TOOH with tubing.
2. Set CIBP at 3525' and cap with 35' of cement.
3. Displace hole with 9# brine with 25#/barrel salt gel.
4. Cut and pull 5-1/2" casing at 2800'±.
5. Run tubing open ended to 2850'. Spot a 25 sack Class "C" 2% CaCl₂ plug. Tag plug.
6. Spot a 25 sack Class "C" 2% CaCl₂ plug from 2500-2400' (across Salt).
7. Spot a 25 sack Class "C" 2% CaCl₂ plug from 450-350' (across 8-5/8" shoe). Tag plug.
8. Spot a 10 sack Class "C" 2% CaCl₂ plug at surface.
9. Install regulation abandonment marker.

NOTE: NOTIFY BLM (887-6544) 24 HOURS PRIOR TO COMMENCING PLUGGING OPERATIONS.

14. I hereby certify that the foregoing is true and correct

Signed

Title Production Clerk

Date April 6, 1994

(This space for Signature of State or Federal Use)

PETROLEUM ENGINEER

PETROLEUM ENGINEER

Approved by Shannon J. Shaw
Conditions of approval, if any:

Title

Date

4/26/94

RECEIVED

APR 20 1994

LOS
OFFICE