

Submit a Copy To Appropriate District
Office
District I - (575) 393-6161
1625 N. French Dr., Hobbs, NM 88240
District II - (575) 748-1283
811 S. First St., Artesia, NM 88210
District III - (505) 334-6178
1000 Rio Brazos Rd., Aztec, NM 87410
District IV - (505) 476-3460
1220 S. St. Francis Dr., Santa Fe, NM
87505

State of New Mexico
Energy, Minerals and Natural Resources

Form C-103
Revised July 18, 2013

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

WELL API NO.
30-005-20082
5. Indicate Type of Lease
STATE [X] FEE []
6. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH
PROPOSALS.)
1. Type of Well: Oil Well [X] Gas Well [] Other []
2. Name of Operator
CANO PETRO OF NEW MEXICO, INC.
3. Address of Operator
801 Cherry St Unit 25 Suite 3200, Fort Worth, TX 76102
4. Well Location
Unit Letter H: 1980 feet from the N line and 660 feet from the E line
Section 22 Township 08S Range 30E NMPM Chaves
11. Elevation (Show whether DR, RKB, RT, GR, etc.)

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:
PERFORM REMEDIAL WORK [] PLUG AND ABANDON [X]
TEMPORARILY ABANDON [] CHANGE PLANS []
PULL OR ALTER CASING [] MULTIPLE COMPL []
DOWNHOLE COMMINGLE []
CLOSED-LOOP SYSTEM []
OTHER: []
SUBSEQUENT REPORT OF:
REMEDIAL WORK [] ALTERING CASING []
COMMENCE DRILLING OPNS. [] P AND A []
CASING/CEMENT JOB []
OTHER: []

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

NMOCD plans to plug this well in accordance with the attached procedure and any agreed modifications thereto.

Spud Date: []

Rig Release Date: []

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE: Ethan Wakefield

TITLE: Authorized Representative

DATE 12/9/25

Type or print name: Ethan Wakefield

E-mail address: e.wakefield@dwsrigs.com

PHONE: 405-343-7736

For State Use Only

APPROVED BY: TITLE DATE

Conditions of Approval (if any):

CANO PETRO OF NEW MEXICO, INC.

Plug And Abandonment Procedure

CATO SAN ANDRES UNIT #135

1980 FNL & 660 FEL, H-22-08S-30E

Chaves County, NM / API: 30-005-20082

1. Hold pre-job safety meeting. Comply with all NMOCD, BLM safety and environmental regulations. Test rig anchors prior to moving in rig if not rigged to base beam.
2. Perform spiral gas check. Check casing, tubing, and Bradenhead pressures.
3. Remove existing piping on casing valve. RU blow lines from casing valves and begin blowing down casing pressure. Perform mandatory 40 bbls well kill. If a different fluid or amount is required kill well as necessary. Ensure the well is dead or on a vacuum.
4. ND wellhead and NU BOP. Function test BOP.
5. P/U 4-1/2" bit or casing scraper on 2-3/8" work string and round trip as deep as possible above top perforation at 3,484'.
6. P/U 4-1/2" CR, TIH and set CR at +/- 3,434'. Pressure test tubing to 1000 psi. Sting out of CR. Load hole and pressure test casing to 800 psi. If casing does not test, then spot or tag subsequent plugs as appropriate. POOH w/ tubing.
 - a. Plug #1 (under CR) may be pumped prior to CBL.
7. RU wireline and run CBL with 500 psi on casing from CR at 3,434' to surface to identify TOC. Adjust plugs as necessary for new TOC. Email log copy to

Loren Diede, Loren.Diede@emnrd.nm.gov and to Gilbert Cordero at gilbert.cordero@emnrd.nm.gov upon completion of logging operations.

8. Rig up to pump cement down tubing. Pump water to establish rate down tubing.
9. Circulate wellbore.

NOTE: All plugs include excess footage to meet requirements.

10. Plug 1: Perforations, Top 3,434', 12 Sacks Type I/II Cement

Mix 12 sx Type I/II cement and squeeze below CR to cover the perforations.

11. Plug 2: Perforations, 3,434'-3,334', 8 Sacks Type I/II Cement

Mix 8 sx Type I/II cement and spot a balanced plug inside casing to cover the Perforations.

12. Plug 3: San Andres Formation Top, 2,810'-2,660', 12 Sacks Type I/II Cement

Mix 12 sx Type I/II cement and spot a balanced plug inside casing to cover the San Andres formation tops.

13. Plug 4: Grayburg and Queen Formation Tops, 2,468'-2,145', 25 Sacks Type I/II Cement

Mix 25 sx Type I/II cement and spot a balanced plug inside casing to cover the Grayburg and Queen formation tops.

14. Plug 5: 7 Rivers and Yates Formation Tops, 1,754'-1,507', 20 Sacks Type I/II Cement

Mix 20 sx Type I/II cement and spot a balanced plug inside casing to cover the 7 Rivers and Yates formation tops.

15. Plug 6: Rustler Formation Top, 1,125'-975', 43 Sacks Type I/II Cement

If determined by CBL perforate at 1,125'. Mix 43 sx Type I/II cement and spot an inside/outside plug to cover the Rustler formation top. If cement is present pump a balanced plug over the same interval.

16. Plug 7: Surface Casing Shoe, 506'-Surface, 174 Sacks Type I/II Cement

Attempt to pressure test the bradenhead annulus to 300 psi; note the volume to load. If BH annulus holds pressure, then establish circulation out casing valve with water. If BH annulus does not test, then perforate at the appropriate depth. Attempt to circulate cement to surface filling the casing from 506' and the annulus from the squeeze holes to surface. Shut in well and WOC.

17. ND cementing valves and cut off wellhead. Fill annuli with cement as necessary. Install P&A marker to comply with regulations. Record GPS coordinate for P&A marker on tower report. Photograph P&A marker in place. RD, MOL and restore location per BLM stipulations.



Existing Wellbore Diagram

CANO PETRO OF NEW MEXICO, INC.
CATO SAN ANDRES UNIT #135
API: 30-005-20082
Chaves County, New Mexico

Surface Casing

8-5/8" 24# @ 456'
OH: 12-1/4"
300 sx

Formation


Rustler - 1075'
Yates - 1607'
7 Rivers - 1704'
Queen - 2245'
Grayburg - 2418'
San Andres - 2760'

Production Casing

4-1/2" 9.5# @ 3693'
OH: 7-7/8"
0.0912 ft³/ft
275 sx

Perforations

3484' to 3583'





Proposed Wellbore Diagram

CANO PETRO OF NEW MEXICO, INC.
CATO SAN ANDRES UNIT #135
API: 30-005-20082
Chaves County, New Mexico

Plug 5
Determine by CBL
1754' to 1507'
247 foot plug
20 sacks Type I/II Cement

Plug 4
Determine by CBL
2468' to 2145'
323 foot plug
25 sacks Type I/II Cement

Plug 3
Determine by CBL
2810' to 2660'
150 foot plug
12 sacks Type I/II Cement

Plug 2
Above CR
3434' to 3334'
100 foot plug
8 sacks Type I/II Cement

Plug 1
SQ Under CR
Top 3434'
12 sacks Type I/II Cement


Surface Casing
8-5/8" 24# @ 456'
OH: 12-1/4"
300 sx

Formation
Rustler - 1075'
Yates - 1607'
7 Rivers - 1704'
Queen - 2245'
Grayburg - 2418'
San Andres - 2760'

Production Casing
4-1/2" 9.5# @ 3693'
OH: 7-7/8"
0.0912 ft³/ft
275 sx

Perforations
3484' to 3583'

CR @ 3434'



Plug 7
Determine by CBL
Assuming Inside/Outside
506' to Surface
174 Sacks of Type I/II Cement

Plug 6
Determine by CBL
Assuming Inside/Outside
1125' to 975'
150 foot plug
43 sacks Type I/II Cement

Sante Fe Main Office
Phone: (505) 476-3441

General Information
Phone: (505) 629-6116

Online Phone Directory
<https://www.emnrd.nm.gov/ocd/contact-us>

State of New Mexico
Energy, Minerals and Natural Resources
Oil Conservation Division
1220 S. St Francis Dr.
Santa Fe, NM 87505

DEFINITIONS

Action 536183

DEFINITIONS

Operator: J.A. Drake Well Service Inc. (OPG Vendor) 607 W. Pinon St Farmington, NM 87401	OGRID: 333581
	Action Number: 536183
	Action Type: [UF-OMA] NOI Plug & Abandon Well (UF-OMA-C-103F)

DEFINITIONS

The OCD Mitigation Activity (OMA) forms are a subset of the OCD's forms exclusively designed for activities related to State of New Mexico's contracted evaluation, plugging, decommissioning, remediation, salvage and reclamation activities. Specifically, these forms are typically used where the OCD has acquired a hearing order allowing the OCD to perform mitigation activities on wells and associated facilities that no longer have an authorized or viable operator to perform the necessary work. These forms are not to be utilized for any other purpose.

Sante Fe Main Office
Phone: (505) 476-3441

General Information
Phone: (505) 629-6116

Online Phone Directory
<https://www.emnrd.nm.gov/ocd/contact-us>

State of New Mexico
Energy, Minerals and Natural Resources
Oil Conservation Division
1220 S. St Francis Dr.
Santa Fe, NM 87505

QUESTIONS

Action 536183

QUESTIONS

Operator: J.A. Drake Well Service Inc. (OPG Vendor) 607 W. Pinon St Farmington, NM 87401	OGRID: 333581
	Action Number: 536183
	Action Type: [UF-OMA] NOI Plug & Abandon Well (UF-OMA-C-103F)

QUESTIONS

Prerequisites	
[OGRID] Well Operator	[248802] CANO PETRO OF NEW MEXICO, INC.
[API] Well Name and Number	[30-005-20082] CATO SAN ANDRES UNIT #135
Well Status	Reclamation Fund Approved

Sante Fe Main Office
Phone: (505) 476-3441

General Information
Phone: (505) 629-6116

Online Phone Directory
<https://www.emnrd.nm.gov/ocd/contact-us>

State of New Mexico
Energy, Minerals and Natural Resources
Oil Conservation Division
1220 S. St Francis Dr.
Santa Fe, NM 87505

CONDITIONS

Action 536183

CONDITIONS

Operator: J.A. Drake Well Service Inc. (OPG Vendor) 607 W. Pinon St Farmington, NM 87401	OGRID: 333581
	Action Number: 536183
	Action Type: [UF-OMA] NOI Plug & Abandon Well (UF-OMA-C-103F)

CONDITIONS

Created By	Condition	Condition Date
loren.diede	Notify NMOCD 24 hours prior to beginning P&A operations. NMOCD has determined that this will is not within the LPCH restricted area and that an above ground P&A marker is required. Submit photo and GPS coordinates of the P&A marker with the C-103P subsequent reports. The API# on the marker must be clearly legible.	12/18/2025