

Jones, William V., EMNRD

From: David_Stewart@oxy.com
Sent: Thursday, August 11, 2011 9:40 AM
To: Jones, William V., EMNRD
Subject: OXY USA Inc. - SWD 1245 - Sundance 4 Federal #32
Attachments: SWD1245-Sundance4Fd32.TIF

Will, a question has come up about the SWD permit for the Sundance 4 Federal #32, API No. 30-015-38393. We drill the well and to 495', set and cemented the surface casing, but we had bad casing and it wouldn't test. We plugged the well to surface, skidded the rig 20' south of the original location and drilled the Sundance 4 Federal #32Y, API No. 30-015-38527.

Original - Sundance 4 Federal #32 - 30-015-38393 - 660 FNL 458 FWL D Sec 4 T24S R31E
Replacement - Sundance 4 Federal #32Y - 30-015-38527 - ~~660~~⁶⁸⁰ FNL 458 FWL D Sec 4 T24S R31E

What do we need to do to transfer the SWD 1245 permit to the replacement well. I appreciate the help.

← RBDMS LOCATION.

Thanks,
David Stewart
Regulatory Advisor
OXY Permian
432-685-5717
Fax-432-685-5742

*David GRAY called yesterday about this SKID-RIG.
AMENDMENT corrects Location, well name, API NUMBER AND
uses OUR LATEST PERMIT LANGUAGE.*

*Will Jones
8/11/11*