

Well Featherstone Fed #1
 Unit J Section 4 Township 19 Range 31
 API# 30-015-05732

T. Salt 7+5
 B. Salt 2190
 Yates 2500
 Glorieta _____
 Delaware _____
 Bone Sp. _____
 Abo _____
 Wolfcamp _____
 Morrow _____
 Devonian _____
 Fusselman _____
 Other _____

270'
 25x
 195
 195 SX
 3
 3371
 3448
 195 SX

← Perf csq @ 60' - circ cmt in & outside
 0'-60'

← Place 100' of cmt 220-320 inside &
 outside of csq. TAG

← Perf csq @ 320'

← Place 100' of cmt 675-775' inside &
 outside of csq - TAG

← Perf csq @ 975'

← Place 100' of cmt 2200-2300' inside &
 outside of csq - TAG

← Perf csq @ 2300'

← 25 SX Plug @ 3300 - TAG

TOC - calc @ 50%

- Contact OCD 24 hrs. prior to any work done.
- Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug
- Install dry hole marker as per rule 202.B.2
- Plugs are to be set from point indicated up. Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- Surface plug will be from 0' - 60'
- Where plugs are required cement must be placed inside and outside of all casing string(s), in the correct footage or sacks required, if no cement exists.
- Plugs to be tagged will be indicated.

BEFORE EXAMINER CATANACH
 OIL CONSERVATION DIVISION
OCD EXHIBIT NO. 22
 CASE NO. 12965