

Well Walch A #2
Unit G Section 4 Township 19 Range 31
API # 30-015--05727

T. Salt 025
B. Salt 0210
Yates 2435
Glorieta _____
Delaware _____
Bone Sp. _____
Abo _____
Wolfcamp _____
Morrow _____
Devonian _____
Fusselman _____
Other _____

→
b
900
505x
← Perf 8⁵/₈" 5¹/₂" @ 60' Place 60' of Cmt
0-60' inside & outside of both
CSG strings
← Place 165' of Cmt 785'-950' inside &
outside of CSG - TAG
← Perf CSG @ 950'
← Place 100' of Cmt 2300'-2400' - Inside &
outside of CSG - TAG
← Perf CSG @ 2400'
97' — TOC @ 50%
← Place 35' of Cmt on Bridge Plug
50' — Permanent Bridge Plug set 5-83
356 — Perfs 785
@ 3474
1255x

- Contact OCD 24 hrs. prior to any work done.
- Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug
- Install dry hole marker as per rule 202.B.2
- Plugs are to be set from point indicated up. Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- Surface plug will be from 0' - 60'
- Where plugs are required cement must be placed inside and outside of all casing string(s), in the correct footage or sacks required, if no cement exists.
- Plugs to be tagged will be indicated.

BEFORE EXAMINER CATANACH	
OIL CONSERVATION DIVISION	
<u>OCD</u>	EXHIBIT NO. <u>28</u>
CASE NO. <u>12965</u>	