

# GEORGE A. DeMERITT

Box 488

Texhoma, Oklahoma 73949

J. N. C. Resources - Johnson #1

September 24, 1986

Trip to location. Rig up. G.O. over mast truck. Ran Gama Ray. Bond log. collar locator. Good Correlation, good cement to 2300'.

October 4, 1986

7:00 AM Trip to location 167 miles. Gunn Camble didn't make it until 4:00 pm. Pipe on location @ 12:00 noon. Set up rig unloaded 116 Jts. 2 7/8 tubing set frac tank to swab back into. Swabed 1800' out of 5 1/2 casing.

7:30 pm Shut down.

October 5, 1986

9:00 AM Crew on location. Swab well dry. Rig up. Blow out preventer Shut down 1:30 pm.

October 6, 1986

8:00 AM Crew on location. Western on Location

9:00 AM G.O. informed me truck in wreck, will start another truck. E.T.H. 2:00 pm.

4:00 pm Perf 3224-38 s S.P.F.

Pumped 500 gals 10% acidic.

Start in hole with packer hit tight spot @ 1350' Come out run in open hole. Ran tubing to 3124' loaded back side pumped 500 gals MRSI hole loaded press to 600 lbs.. Shut down. Bring up in 200 # inc. to 1900# formation broke and treated @ 2200 # 3½ BPM. Ran 40 ball sealers. Press increase to 26# with ball action. ISP 2100# 1700# 5 min. Swab test recovering drilling mud and treatment water.

October 7, 1986

Swedge and tools came in. Run in hole to fix casing trip in and trip out. Ready to retreat well in A.M.

October 8, 1986

Trip in with Mod R. Packer set @ 3150' retreat well with 500 gals 7½% HCL acid followed with 1000 gals MRSI flush with 2% KCL. Trip out of hole to set C.I.B.P. @ 3170' Still drilling mud and filtrate water. Start in hole to rig up to swab hole dry.