

Memo

From

E. G. Kapteina, Engineer

Plugging Program

2. Jack Dean #1

10 sac ^{cement} plug @ 34.5'

15 sac cement plug @ point 7" casing
shot off

10 sac @ 1125'

10 sac @ 725'

15 sac @ surface

Fill intervals
between plugs w/
heavy mud

4" steel marker set in cement at
surface and extending 4' above
mean ground level.

