

1238 still intend to cement hole and case off

1238 dropped 50 sk to bottom to stop caving

1253 cement holding caving

1343 run 1240' 6" pipe. cut w/ 151 sk.

1343 wtr coming into pipe @ 1014. Later corrected to 814.
wtr stands @ 180' from surface (1263' water in hole)

1343 spotted 200 sk @ 1012; water stands 1193' deep in
annulus; stands 543' deep in casing. (rises 24'/24 hrs)

1343 attempt to cement "bad spot" @ 795'. tools cemented in.
six inch parted @ 794. one joint reportedly fell out
of string. top of string @ 794 w/ tools cemented
in top of them.