STATE OF TACM TATEMEN

Form C-103

DIS	TRIC	\mathbf{T}			
P.O.	Box	1980,	Hobbs,	NM	88240

to Appropriate District Office	Energy, Minerals and Natural R	Revised 1-1-89			
DISTRICT I P.O. Box 1980, Hobbs, NM 88240	OIL CONSERVATIO		WELL API NO.		
DISTRICT II	Santa Fe, N			59-20066	
P.O. Drawer DD, Artesia, NM 88210			5. Indicate Type	of Lesse STATE F	ÈE 🗴
DISTRICT III 1000 Rio Brazos Rd., Aziec, NM 87410			6. State Oil & 0	ias Lease No.	
(DO NOT USE THIS FORM FOR PRODIFFERENT RESERVICES (FORM COMPANY)	CES AND REPORTS ON WE PPOSALS TO DRILL OR TO DEEPEN RVOIR. USE "APPLICATION FOR PE 101) FOR SUCH PROPOSALS.)	OR PLUG BACK TO A	7. Lease Name	or Unit Agreement Name	
1. Type of Well: OIL GAS WELL WELL	отнех СО2			Bocogu-20	34
2 Name of Operator Amoco Production	Company		8. Well No.	231	
3. Address of Operator PO Box 606, Clayt	on, NM 88415		9. Pool name or	Wildcat Tubb	
4. Well Location Unit Letter K : 19	80 Feet From The South	198	O Feet Fro	om The	Line
Section 23		34E	NMPM	Union	County
	10. Elevation (Show whether 4717' G	DF, RKB, RT, GR, etc.)			
11. Check A	Appropriate Box to Indicate 1	Nature of Notice, Re	eport, or Othe	er Data	
NOTICE OF INT	ENTION TO:	SUB	SEQUENT	REPORT OF:	
PERFORM REMEDIAL WORK	PLUG AND ABANDON	REMEDIAL WORK		ALTERING CASING	
TEMPORARILY ABANDON	CHANGE PLANS	COMMENCE DRILLING	OPNS.	PLUG AND ABANDONN	IENT 📙
PULL OR ALTER CASING		CASING TEST AND CEMENT JOB			
OTHER: Inst	all Casing Liner X	OTHER:			[
12. Describe Proposed or Completed Operation work) SEE RULE 1103.	ons (Clearly state all pertinent details, ar	nd give pertinent dates, includ	ling estimated date	of starting any proposed	
MINITORY	SNUB AND POLYB	ORE PROCEDURE			
MIRUSU RUN & SET 1.625 BLK 1 BLEED DOWN TBG NIPPLE UP BOP REL ON/OFF TOOL SWAB & BLOW WELL! LAY DOWN FG TBG & RUN POLYBORE GAUC CHANGE RAMS IN BOF RUN ON/OFF TOOLOS LATCH ON TO PKR WARIG UP RIG ASSISTED S REL PKR	PLG IN PROFILE NIP DRY ON/OFF TOOL OS DE RING TO PKR ON/SW WS SNUBBING UNIT	NSTALL PRODUCTION RWTP UP 5.5 STEEL OF PRODUCE FOR 12 TO MOVE IN RIG UP SER SHUT IN BOP-BLINDS RUN BAKER WIRE LISET IBP ABOVE TOP BLEED CSG TO 0 PSI RUN 9-31/8" DRILL CORIG UP RRU POLYLINER TO RUN 23/8" WORK STR FUSE ON WELLHEAD	ESG 20 DAYS VICE UNIT S NE ,SET INFLATI PERF DLLARS INFLATTABLE B ING & PULL DRI	P	
SNUB TBG, PKR, TAILP SHUT IN WELL W/BLIN		INSTALL SS ADAPTE	₹	:	

MIRUSU **RUN & SET** BLEED DOW NIPPLE UP B REL ON/OFF SWAB & BLO LAY DOWN RUN POLYB CHANGE RA RUN ON/OFF LATCH ON T RIG UP RIG A REL PKR SNUB TBG, P SHUT IN WE RIG DOWN SNUBBING UNIT INSTALL SS WELLHEAD BONNET ON TOP OF BOP

RETRIEVE IBP WITH WIRELINE RWTP RDMOSU

ny knowledge and belief. Field Foreman DATE 2/27/97 SIGNATURE _ TYPE OR PRINT NAME **ТЕГЕРНОНЕ NO. 374-3053** Prichard

(This space for State Us

CONDITIONS OF APPROVAL, IF ANY