Submit 3 Copies	State of New Mexico			Form C-103	
o Appropriate	Energy, Minerals, and Natural Resources Department			Revised 1-1-89	
District Office					
DISTRICT I	OIL CONSERVATION DIVISION		WELL API NO.	WELL API NO.	
P.O. Box 1980, Hobbs, NM 88240	P.O. Box 2088		30-059-201	30-059-20127	
DISTRICT II	Santa Fe, New Mexico 87504-2088		5. Indicate Type of I	9369	
2.O. Drawer DD, Artesia, NM 88210	54114 7 61, 1011 HAZAREV 0750 V 2555		STATE	FEE	
.O. Dianet DD, Attesta, 1101 00210					
DISTRICT III			6. State Oil & Gas L	ease No.	
000 Rio Brazos Rd., Aztec, NM 87410					
SUNDR	Y NOTICES AND REPORTS ON W	/ELLS			
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A					
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"			7. Lease Name or Un	7. Lease Name or Unit Agreement Name	
(FORM C-101) FOR SUCH PROPOSALS.)				_	
Type of Well			BRAVO DOME C	O2 GAS UNIT	
	GAS OTHER	CO2			
	WELL		0.32.43.		
Name of Operator			8. Well No.	1	
AMOCO PRODUCTION COMPANY			2333-2	2333-251F	
Address of Operator			9. Pool name or Wild	9. Pool name or Wildcat	
P.O. Box 303, AMISTAD, NEW MEXICO 88410			BRAVO DOME C	BRAVO DOME CO2 GAS UNIT	
Well Location					
	1980 Feet From The North	Line and 198	Feet From The	West Line	
Section 25	Township 23N	Range 33E	NMPM Union	County	
Section 29			.v.n.vi	County	
	10. Elevation (Show whe	ther DF, RKB, RT, GR, etc.) GR			
			<del> </del>		
Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data					
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:					
	PLUG AND ABANDON	REMEDIAL WORK		ERING CASING	
ERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK			ALII	ERING CASING	
EMPORARILY ABANDON	MPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OPNS. PLUG AND ABANDONMENT				
ULL OR ALTER CASING	ALTER CASING CASING TEST AND CEMENT JOB				
)THER:		OTHER -			
2. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.					
10-10-99					
MIRUSU, casing pressure = 0 psi, NUBOP, run 2 3/8" workstring, tag existing CIBP at 2,230 feet, displace casing with fresh					
water with corrision inhibited fluid, pressure test casing to 500 psi, ok. Spot 5 sacks of Class C cement from 2230' - 2157',					
pull workstring to 1,887 feet, spot 15 sacks of cement from 1887' - 1772', pull workstring to 30 feet, fill casing with cement,					
NDBOP, cut off wellhead, install PXA marker, RDMOSU, cut off well anchors and clean location.					
als/od ok REJ					
			at RE		
nereby certify that the information above is true and complete to the best of my knowledge and belief.					
(11)1,	D 11				
GNATURE () 150	TITLETITLE	Field Foreman	DATE	10-13-99	
TPE OR PRINT NAME Danny J. Ho	olcool b		TELEPHON	E NO. (505) 374-3010	
his space for State Use)	5111/	and the same form to the same of the same		//	
PPROVED BY	C Nothern TITLE	DISTRICT SUP	SRVISOR DATE 6	3/10/00	
ONDITIONS OF APPROVAL, IF ANY:		· - · <del></del>			