

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE*
(Other instructions on reverse side)

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.
IM 12835

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

Federal

7. UNIT AGREEMENT NAME

None

8. FARM OR LEASE NAME

C. Morris

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

wildcat

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

Sec 34-T7N-R6W, N.M.P.M.

12. COUNTY OR PARISH

Valencia

13. STATE

New Mexico

SUNDRY NOTICES AND REPORTS ON WELLS
(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☐ GAS WELL ☐ OTHER **Dry**

2. NAME OF OPERATOR

Morris & Jones

3. ADDRESS OF OPERATOR

900 Bank of New Mexico Building, Albuquerque, New Mexico

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.)
At surface

775' EAL, 2050' SAL

14. PERMIT NO.

U.S.G.S. 3-7-74

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

6185' CR, 6196' KB

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☐

REPAIR WELL ☐

(Other) ☐

PULL OR ALTER CASING ☐

MULTIPLE COMPLETE ☐

ABANDON* ☐

CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐

FRACTURE TREATMENT ☐

SHOOTING OR ACIDIZING ☐

(Other) ☐

REPAIRING WELL ☐

ALTERING CASING ☐

ABANDONMENT* ☒

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Per verbal approval received on July 22, 1974, from Jerry C. Long, U.S.G.S. District Engineer, well was plugged and abandoned as follows:

Set 20 sack cement plug from 2712' to 2702'. Set cast iron bridge plug at 2612' and set 45 sack cement plug from 2612' to 2600'. Set 30 sack cement plug from 2600' to 2550'. Set 15 sack cement plug from 245' to 175'. Set 15 sack cement plug in surface.

Cleaned location and installed dry hole marker. Work completed July 29, 1974.

RECEIVED
AUG 21 1974
OIL CONSERVATION
Santa Fe, N.M.

18. I hereby certify that the foregoing is true and correct

SIGNED

Original Signed by
MCRRIS B. JONES

TITLE

Consulting Engineer

DATE

7/29/74

(This space for Federal or State office use)

APPROVED BY

TITLE

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED
AUG 19 1974

*See Instructions on Reverse Side

U.S. GEOLOGICAL SURVEY
BOULDER, COLO.

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.