| Office | State of New Mexico | Form C-103 | | |
|--|---|---|--|--|
| Office District I | Energy, Minerals and Natural Resources | March 4, 2004 | | |
| 1625 N French Dr., Hobbs, NM 88240 | | WELL API NO. | | |
| District II | OIL CONSERVATION DIVISION | 30-005-60541 | | |
| 1301 W. Grand Ave., Artesia, NM 88210 District III | 1220 South St. Francis Dr. | 5. Indicate Type of Lease | | |
| 1000 Rio Brazos Rd., Aztec, NM 87410 | | STATE X FEE | | |
| District IV | Santa Fe, NM 87505 | 6. State Oil & Gas Lease No. | | |
| 1220 S. St. Francis Dr., Santa Fe, NM 87505 | | | | |
| | CES AND REPORTS ON WELLS | 7. Lease Name or Unit Agreement Name | | |
| (DO NOT USE THIS FORM FOR PROPOS | CES AND REPORTS ON WELLS ALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A ATION FOR PERMIT" (FORM C-101) FOR SUCH 2 3 | Buckhorn AYU State Com | | |
| DIFFERENT RESERVOIR. USE "APPLIC | ATION FOR PERMIT" (FORM C-101) FOR SUCH 2 3 | | | |
| 1. Type of Well: | 829 | 8. Well Number | | |
| Oil Well Gas Well | | (1 | | |
| 2. Name of Operator | /66 50; 7001 | 9. OGRID Number | | |
| Yates Petroleum Corporation | RECEIVED | 025575 | | |
| 3. Address of Operator | IM 88210 | | | |
| 105 South Fourth Street, Artesia, N | M 88210 \mathcal{C} | Wildcat | | |
| 4. Well Location | | | | |
| Unit Letter O : 99 | on feet from the South 0 26 line pull ch | 980 feet from the East line | | |
| <u> </u> | source Source Splishing T | Post non the Bust inc | | |
| Section 18 | Township 19S Range 20E | NMPM Chaves County | | |
| The article of the second of the second of | 11. Elevation (Show whether DR, RKB, RT, GR, etc. | | | |
| | 4724'GR | | | |
| Pit or Below-grade Tank Application (For | pit or below-grade tank closures, a form C-144 must be attache | <u>d)</u> | | |
| Pit Location: UL Sect Twp | Rng Pit type Depth to Groundwater | Distance from nearest fresh water well | | |
| | Below-grade Tank Location UL Sect Twp | | | |
| | | , | | |
| feet from theline and | feet from theline | | | |
| 12. Check A | ppropriate Box to Indicate Nature of Notice, | Report or Other Data | | |
| NOTICE OF IN PERFORM REMEDIAL WORK | | SEQUENT REPORT OF: K | | |
| | | K ALTERING CASING LLING OPNS. PLUG AND X | | |
| PERFORM REMEDIAL WORK | PLUG AND ABANDON REMEDIAL WOR | K ALTERING CASING LLING OPNS. PLUG AND ABANDONMENT | | |
| PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: | PLUG AND ABANDON REMEDIAL WOR CHANGE PLANS COMMENCE DRI MULTIPLE CASING TEST AI CEMENT JOB OTHER: | ALTERING CASING LLING OPNS. PLUG AND X ABANDONMENT D | | |
| PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: | PLUG AND ABANDON REMEDIAL WOR CHANGE PLANS COMMENCE DRI MULTIPLE CASING TEST AI CEMENT JOB | ALTERING CASING LLING OPNS. PLUG AND X ABANDONMENT D | | |
| PERFORM REMEDIAL WORK TEMPORARILY ABANDON DULL OR ALTER CASING DULL OR A | PLUG AND ABANDON REMEDIAL WOR CHANGE PLANS COMMENCE DRI MULTIPLE CASING TEST AI CEMENT JOB OTHER: | ALTERING CASING LLING OPNS. PLUG AND ABANDONMENT ABANDONMENT d give pertinent dates, including estimated date | | |
| PERFORM REMEDIAL WORK TEMPORARILY ABANDON DULL OR ALTER CASING OTHER: 13. Describe proposed or complete. | PLUG AND ABANDON REMEDIAL WOR CHANGE PLANS COMMENCE DRI MULTIPLE CASING TEST AI CEMENT JOB OTHER: eted operations. (Clearly state all pertinent details, and | ALTERING CASING LLING OPNS. PLUG AND ABANDONMENT ABANDONMENT d give pertinent dates, including estimated date | | |
| PERFORM REMEDIAL WORK TEMPORARILY ABANDON DULL OR ALTER CASING DULL OR ALTER CASING DULL OR Starting any proposed or completion or recompletion. | PLUG AND ABANDON REMEDIAL WOR CHANGE PLANS COMMENCE DRI MULTIPLE CASING TEST AI CEMENT JOB OTHER: eted operations. (Clearly state all pertinent details, and rk). SEE RULE 1103. For Multiple Completions: At | LLING OPNS. PLUG AND X ABANDONMENT ABANDONMENT d give pertinent dates, including estimated date tach wellbore diagram of proposed completion | | |
| PERFORM REMEDIAL WORK TEMPORARILY ABANDON DULL OR ALTER CASING DTHER: 13. Describe proposed or completion of starting any proposed work or recompletion. 5/19/04 – RIH with 2-3/8" tubing. Temporary Tempora | PLUG AND ABANDON REMEDIAL WOR CHANGE PLANS COMMENCE DRI MULTIPLE CASING TEST AI CEMENT JOB OTHER: eted operations. (Clearly state all pertinent details, and | LLING OPNS. PLUG AND X ABANDONMENT ABANDONMENT d give pertinent dates, including estimated date tach wellbore diagram of proposed completion | | |
| PERFORM REMEDIAL WORK TEMPORARILY ABANDON DULL OR ALTER CASING DTHER: 13. Describe proposed or completion of starting any proposed work or recompletion. 5/19/04 – RIH with 2-3/8" tubing. Teplug. | PLUG AND ABANDON REMEDIAL WOR CHANGE PLANS COMMENCE DRI MULTIPLE CASING TEST AI CEMENT JOB OTHER: eted operations. (Clearly state all pertinent details, and rk). SEE RULE 1103. For Multiple Completions: At agged at 3928'. Circulated hole with salt gel. POOH | ALTERING CASING LLING OPNS. PLUG AND ABANDONMENT D d give pertinent dates, including estimated date tach wellbore diagram of proposed completion to 3827'. Spotted 25 sx Class "C" cement | | |
| PERFORM REMEDIAL WORK TEMPORARILY ABANDON DULL OR ALTER CASING DTHER: 13. Describe proposed or complor of starting any proposed work or recompletion. 5/19/04 - RIH with 2-3/8" tubing. Teplug. 5/20/04 - Tagged cement plug at 355 | PLUG AND ABANDON REMEDIAL WOR CHANGE PLANS COMMENCE DRI MULTIPLE CASING TEST AI CEMENT JOB OTHER: eted operations. (Clearly state all pertinent details, and rk). SEE RULE 1103. For Multiple Completions: At agged at 3928'. Circulated hole with salt gel. POOH 11'. POOH with tubing to 3000'. Spotted 25 sx Class | ALTERING CASING LLING OPNS. PLUG AND X ABANDONMENT ABANDONMENT d give pertinent dates, including estimated date tach wellbore diagram of proposed completion to 3827'. Spotted 25 sx Class "C" cement "C" cement plug. POOH with tubing to 2350'. | | |
| PERFORM REMEDIAL WORK TEMPORARILY ABANDON DULL OR ALTER CASING DTHER: 13. Describe proposed or complos of starting any proposed work or recompletion. 5/19/04 - RIH with 2-3/8" tubing. Teplug. 5/20/04 - Tagged cement plug at 355 Spotted 25 sx Class "C" cement plug | PLUG AND ABANDON REMEDIAL WOR CHANGE PLANS COMMENCE DRI MULTIPLE COMPLETION CASING TEST AI CEMENT JOB OTHER: eted operations. (Clearly state all pertinent details, and rk). SEE RULE 1103. For Multiple Completions: At agged at 3928'. Circulated hole with salt gel. POOH 11'. POOH with tubing to 3000'. Spotted 25 sx Class POOH with tubing at 1850'. Spotted 25 sx Class "Completions". | ALTERING CASING LLING OPNS. PLUG AND X ABANDONMENT ABANDONMENT d give pertinent dates, including estimated date tach wellbore diagram of proposed completion to 3827'. Spotted 25 sx Class "C" cement "C" cement plug. POOH with tubing to 2350'. | | |
| PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or complosed farting any proposed work or recompletion. 5/19/04 - RIH with 2-3/8" tubing. Teplug. 5/20/04 - Tagged cement plug at 355 Spotted 25 sx Class "C" cement plug plug at 1538'. Perforate 4-1/2" casin | PLUG AND ABANDON REMEDIAL WOR CHANGE PLANS COMMENCE DRI MULTIPLE CASING TEST AI CEMENT JOB OTHER: eted operations. (Clearly state all pertinent details, and rk). SEE RULE 1103. For Multiple Completions: At agged at 3928'. Circulated hole with salt gel. POOH 1'. POOH with tubing to 3000'. Spotted 25 sx Class POOH with tubing at 1850'. Spotted 25 sx Class "Cog at 224'. Circulated cement to surface. WOC. | ALTERING CASING LLING OPNS. PLUG AND ABANDONMENT D d give pertinent dates, including estimated date tach wellbore diagram of proposed completion to 3827'. Spotted 25 sx Class "C" cement "C" cement plug. POOH with tubing to 2350'. "cement plug. WOC 4 hrs. Tagged cement | | |
| PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or complosed farting any proposed work or recompletion. 5/19/04 - RIH with 2-3/8" tubing. Teplug. 5/20/04 - Tagged cement plug at 355 Spotted 25 sx Class "C" cement plug plug at 1538'. Perforate 4-1/2" casin | PLUG AND ABANDON REMEDIAL WOR CHANGE PLANS COMMENCE DRI MULTIPLE COMPLETION CASING TEST AI CEMENT JOB OTHER: eted operations. (Clearly state all pertinent details, and rk). SEE RULE 1103. For Multiple Completions: At agged at 3928'. Circulated hole with salt gel. POOH 11'. POOH with tubing to 3000'. Spotted 25 sx Class POOH with tubing at 1850'. Spotted 25 sx Class "Completions". | ALTERING CASING LLING OPNS. PLUG AND ABANDONMENT D d give pertinent dates, including estimated date tach wellbore diagram of proposed completion to 3827'. Spotted 25 sx Class "C" cement "C" cement plug. POOH with tubing to 2350'. "cement plug. WOC 4 hrs. Tagged cement | | |
| PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or complosed farting any proposed work or recompletion. 5/19/04 - RIH with 2-3/8" tubing. Teplug. 5/20/04 - Tagged cement plug at 355 Spotted 25 sx Class "C" cement plug plug at 1538'. Perforate 4-1/2" casin | PLUG AND ABANDON REMEDIAL WOR CHANGE PLANS COMMENCE DRI MULTIPLE CASING TEST AI CEMENT JOB OTHER: eted operations. (Clearly state all pertinent details, and rk). SEE RULE 1103. For Multiple Completions: At agged at 3928'. Circulated hole with salt gel. POOH 1'. POOH with tubing to 3000'. Spotted 25 sx Class POOH with tubing at 1850'. Spotted 25 sx Class "Cog at 224'. Circulated cement to surface. WOC. | ALTERING CASING LLING OPNS. PLUG AND ABANDONMENT D d give pertinent dates, including estimated date tach wellbore diagram of proposed completion to 3827'. Spotted 25 sx Class "C" cement "C" cement plug. POOH with tubing to 2350'. "cement plug. WOC 4 hrs. Tagged cement | | |
| PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or complos of starting any proposed work or recompletion. 5/19/04 - RIH with 2-3/8" tubing. Toplug. 5/20/04 - Tagged cement plug at 355 Spotted 25 sx Class "C" cement plug plug at 1538'. Perforate 4-1/2" casin 5/23/04 - Tagged cement plug on we | PLUG AND ABANDON REMEDIAL WORD CHANGE PLANS COMMENCE DRI MULTIPLE COMPLETION CASING TEST AI CEMENT JOB OTHER: eted operations. (Clearly state all pertinent details, and rk). SEE RULE 1103. For Multiple Completions: At agged at 3928'. Circulated hole with salt gel. POOH 11'. POOH with tubing to 3000'. Spotted 25 sx Class POOH with tubing at 1850'. Spotted 25 sx Class "C g at 224'. Circulated cement to surface. WOC. Ilhead. Installed dry hole marker. WELL IS PLUGG | ALTERING CASING LLING OPNS. PLUG AND ABANDONMENT ABANDONMENT D d give pertinent dates, including estimated date tach wellbore diagram of proposed completion to 3827'. Spotted 25 sx Class "C" cement "C" cement plug. POOH with tubing to 2350'. "cement plug. WOC 4 hrs. Tagged cement ED AND ABANDONED. FINAL REPORT. | | |
| PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or complosed of starting any proposed work or recompletion. 5/19/04 - RIH with 2-3/8" tubing. Toplug. 5/20/04 - Tagged cement plug at 355 Spotted 25 sx Class "C" cement plug plug at 1538'. Perforate 4-1/2" casin 5/23/04 - Tagged cement plug on we | PLUG AND ABANDON REMEDIAL WOR CHANGE PLANS COMMENCE DRI MULTIPLE CASING TEST AI CEMENT JOB OTHER: eted operations. (Clearly state all pertinent details, and rk). SEE RULE 1103. For Multiple Completions: At agged at 3928'. Circulated hole with salt gel. POOH 1'. POOH with tubing to 3000'. Spotted 25 sx Class. POOH with tubing at 1850'. Spotted 25 sx Class "Og at 224'. Circulated cement to surface. WOC. lilhead. Installed dry hole marker. WELL IS PLUGG above is true and complete to the best of my knowledge | LLING OPNS. PLUG AND ABANDONED. FINAL REPORT. ALTERING CASING DATE AND ABANDONED. PLUG AND ABANDONED. PLUG AND ABANDONED. PLUG AND ABANDONED. PLUG AND ABANDONED. FINAL REPORT. | | |
| PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or complosed of starting any proposed work or recompletion. 5/19/04 - RIH with 2-3/8" tubing. Toplug. 5/20/04 - Tagged cement plug at 355 Spotted 25 sx Class "C" cement plug plug at 1538'. Perforate 4-1/2" casin 5/23/04 - Tagged cement plug on we | PLUG AND ABANDON REMEDIAL WORD CHANGE PLANS COMMENCE DRI MULTIPLE COMPLETION CASING TEST AI CEMENT JOB OTHER: eted operations. (Clearly state all pertinent details, and rk). SEE RULE 1103. For Multiple Completions: At agged at 3928'. Circulated hole with salt gel. POOH 11'. POOH with tubing to 3000'. Spotted 25 sx Class POOH with tubing at 1850'. Spotted 25 sx Class "C g at 224'. Circulated cement to surface. WOC. Ilhead. Installed dry hole marker. WELL IS PLUGG | LLING OPNS. PLUG AND ABANDONED. FINAL REPORT. ALTERING CASING DATE AND ABANDONED. PLUG AND ABANDONED. PLUG AND ABANDONED. PLUG AND ABANDONED. PLUG AND ABANDONED. FINAL REPORT. | | |
| PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or complosed of starting any proposed work or recompletion. 5/19/04 - RIH with 2-3/8" tubing. Toplug. 5/20/04 - Tagged cement plug at 355 Spotted 25 sx Class "C" cement plug plug at 1538'. Perforate 4-1/2" casin 5/23/04 - Tagged cement plug on we | PLUG AND ABANDON REMEDIAL WORD CHANGE PLANS COMMENCE DRI MULTIPLE COMPLETION CASING TEST AI CEMENT JOB OTHER: eted operations. (Clearly state all pertinent details, and rk). SEE RULE 1103. For Multiple Completions: At agged at 3928'. Circulated hole with salt gel. POOH 1'. POOH with tubing to 3000'. Spotted 25 sx Class POOH with tubing at 1850'. Spotted 25 sx Class "Cg at 224'. Circulated cement to surface. WOC. Ilhead. Installed dry hole marker. WELL IS PLUGG: Above is true and complete to the best of my knowledge closed according to NMOCD guidelines, a general permit | ALTERING CASING LLING OPNS. PLUG AND ABANDONMENT d give pertinent dates, including estimated date tach wellbore diagram of proposed completion to 3827'. Spotted 25 sx Class "C" cement "C" cement plug. POOH with tubing to 2350'. "cement plug. WOC 4 hrs. Tagged cement ED AND ABANDONED. FINAL REPORT. e and belief. I further certify that any pit or below- or an (attached) alternative OCD-approved plan | | |
| PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or complosed of starting any proposed work or recompletion. 5/19/04 - RIH with 2-3/8" tubing. Toplug. 5/20/04 - Tagged cement plug at 355 Spotted 25 sx Class "C" cement plug plug at 1538'. Perforate 4-1/2" casin 5/23/04 - Tagged cement plug on we | PLUG AND ABANDON REMEDIAL WOR CHANGE PLANS COMMENCE DRI MULTIPLE CASING TEST AI CEMENT JOB OTHER: eted operations. (Clearly state all pertinent details, and rk). SEE RULE 1103. For Multiple Completions: At agged at 3928'. Circulated hole with salt gel. POOH 1'. POOH with tubing to 3000'. Spotted 25 sx Class. POOH with tubing at 1850'. Spotted 25 sx Class "Og at 224'. Circulated cement to surface. WOC. lilhead. Installed dry hole marker. WELL IS PLUGG above is true and complete to the best of my knowledge | ALTERING CASING LLING OPNS. PLUG AND ABANDONMENT d give pertinent dates, including estimated date tach wellbore diagram of proposed completion to 3827'. Spotted 25 sx Class "C" cement "C" cement plug. POOH with tubing to 2350'. "cement plug. WOC 4 hrs. Tagged cement ED AND ABANDONED. FINAL REPORT. e and belief. I further certify that any pit or below- or an (attached) alternative OCD-approved plan | | |
| PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or complosed of starting any proposed work or recompletion. 5/19/04 - RIH with 2-3/8" tubing. Toplug. 5/20/04 - Tagged cement plug at 355 Spotted 25 sx Class "C" cement plug plug at 1538'. Perforate 4-1/2" casin 5/23/04 - Tagged cement plug on we | PLUG AND ABANDON | ALTERING CASING LLING OPNS. PLUG AND ABANDONMENT d give pertinent dates, including estimated date tach wellbore diagram of proposed completion to 3827'. Spotted 25 sx Class "C" cement "C" cement plug. POOH with tubing to 2350'. "cement plug. WOC 4 hrs. Tagged cement ED AND ABANDONED. FINAL REPORT. e and belief. I further certify that any pit or below- or an (attached) alternative OCD-approved plan . Supervisor DATE: June 30, 2004 | | |
| PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or complosed of starting any proposed work or recompletion. 5/19/04 - RIH with 2-3/8" tubing. Toplug. 5/20/04 - Tagged cement plug at 355 Spotted 25 sx Class "C" cement plug plug at 1538'. Perforate 4-1/2" casin 5/23/04 - Tagged cement plug on we I hereby certify that the information a grade tank has been/will be constructed or estimated the start of the star | PLUG AND ABANDON | ALTERING CASING LLING OPNS. PLUG AND ABANDONMENT d give pertinent dates, including estimated date tach wellbore diagram of proposed completion to 3827'. Spotted 25 sx Class "C" cement "C" cement plug. POOH with tubing to 2350'. "cement plug. WOC 4 hrs. Tagged cement ED AND ABANDONED. FINAL REPORT. e and belief. I further certify that any pit or below- or an (attached) alternative OCD-approved plan . Supervisor DATE: June 30, 2004 | | |
| PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or complosed of starting any proposed work or recompletion. 5/19/04 - RIH with 2-3/8" tubing. Toplug. 5/20/04 - Tagged cement plug at 355 Spotted 25 sx Class "C" cement plug plug at 1538'. Perforate 4-1/2" casin 5/23/04 - Tagged cement plug on we I hereby certify that the information a grade tank has been/will be constructed or estimated the start of the star | PLUG AND ABANDON | ALTERING CASING LLING OPNS. PLUG AND ABANDONMENT d give pertinent dates, including estimated date tach wellbore diagram of proposed completion to 3827'. Spotted 25 sx Class "C" cement "C" cement plug. POOH with tubing to 2350'. "cement plug. WOC 4 hrs. Tagged cement ED AND ABANDONED. FINAL REPORT. e and belief. I further certify that any pit or below- or an (attached) alternative OCD-approved plan . Supervisor DATE: June 30, 2004 | | |
| PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or complos of starting any proposed work or recompletion. 5/19/04 - RIH with 2-3/8" tubing. Toplug. 5/20/04 - Tagged cement plug at 355 Spotted 25 sx Class "C" cement plug plug at 1538'. Perforate 4-1/2" casin 5/23/04 - Tagged cement plug on we I hereby certify that the information a grade tank has been/will be constructed or SIGNATURE Type or print name Tina Huert | PLUG AND ABANDON | ALTERING CASING LLING OPNS. PLUG AND ABANDONMENT d give pertinent dates, including estimated date tach wellbore diagram of proposed completion to 3827'. Spotted 25 sx Class "C" cement "C" cement plug. POOH with tubing to 2350'. "cement plug. WOC 4 hrs. Tagged cement ED AND ABANDONED. FINAL REPORT. e and belief. I further certify that any pit or below- or an (attached) alternative OCD-approved plan . Supervisor DATE: June 30, 2004 | | |



Mailed 1-27-05 fun K ang NEW MEXICO ENERGY, MINERALS and MT - Proce NATURAL RESOURCES DEPARTMENT 1-25-6

GARY E. JOHNSON
Governor
Betty Rivera
Cabinet Secretary

Lori Wrotenbery
Director
Oil Conservation Division

RECEIVED

JAN 28 2005

Yates Petroleum Corporation 105 South 4th Street Artesia, New Mexico 88210 note: re-entry unsuccessful.

Form C-103 Report of Plugging for your Buckhorn Ayu St. Com 41- Sec. 18-7195. Race - 30-005-60541 Cannot be approved until an NMOCD representative has made an inspection of the location and found it to be cleared to comply with OCD rules and regulations. Please check each item in the space provided to indicate that the work has been accomplished and the location is ready for final inspection.

| _ / | • | | | | | |
|--------------|----|---------------|------|--------|-----|----------|
| \mathbf{Z} | 1. | All pits have | been | filled | and | leveled. |

2. Rat hole and cellar have been filled and leveled.

3. A steel marker 4" in diameter and approximately 4' above mean ground level has been set in concrete to mark the exact location of the plugged well. (Marker must have operator name, lease name, well number and location including quarter/quarter section or unit letter, section, township, range and API well ID number permanently welded, stamped or otherwise engraved into the metal marker.)

The location has been leveled as nearly as possible to original top ground contour and has been cleared of all junk and equipment.

5. The dead men and tie downs have been cut and removed.

6. If a one well lease or last remaining well on lease, the battery and burn pit locations have been leveled and cleared of all junk & equipment.

7. All environmental concerns have been addressed as per OCD guidelines.

The above are minimum requirements and no plugging bond will be cancelled until all locations for plugged and abandoned wells have been inspected and Form C-103 approved.

When all of the work outlined above has been done, please notify this office by completing, signing and returning this letter to us so that our representative will not have to make more than one trip to the location.

I certify that the above work has been done and the above-mentioned lease is ready for OCD inspection and approval.

Manle Morfs 1/25/05

Van Barton
Field Rep. II

Title