

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT-" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator

CHI OPERATING, INC.

3. Address and Telephone No.

P.O. BOX 1799 MIDLAND, TEXAS 79702

4. Location of Well (Footage, T., R., M., or Survey Description)

1980' FNL & 1980' FWL, Sec. 11-T22S-R25E

5. Lease Designation and Serial No.

89805

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Big Mac Federal Com. #1

9. API Well No.

30-015-31431

10. Field and Pool, or Exploratory Area

Revelation Morrow

11. County or Parish, State

Eddy County, NM

RECEIVED

JUN 30 2005

OCD-ARTESIA

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other
☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Plug & Abandon Start date 8-01-05 See Attached

14. I hereby certify that the foregoing is true and correct.

Signed Robert Stew Title Regulatory Clerk Date 6/28/2005

(This space for Federal or State office use)

Approved by _____ Title _____ Date _____
Conditions of approval, if any:

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

*See Instructions on Reverse Side

Accepted for record - NMOCD

Big Mac Federal Com No. 1 Plug and Abandon Procedure

CURRENT WELLBORE:

KB 13'
Surf Csg: @ 361' 13-3/8", 48#, J-55
Int Csg: @ 2255' 8 5/8", 24#, J-55

Prod Csg.: @ 11111' 5½"-17# - N-80 - LT&C
DV Collar @ 4,772'
Float Collar @ 11,063'. Marker Jt. #25 @ 10,052' - 34.78'
Est. TOC: 1st stage: 8,000'
2nd stage: 2,000'
Perfs: Morrow: 10,762-10,772' and 10,634-10,640' CIBP @10735' w/35' cmt;
10634-10640' CIBP @ 10600' w/35' cmt.
Penn: 9785-9791' CIBP @9750' w/35 sx cmt; 9048-9053', 9024-9030',
9007-9020', 8963-8967'

- 1) **RU DD PU. Circulate hole w/ mud laden fluid. POOH w/ packer and production tubing.**
- 2) **Set CIBP at 8950' spot 35' of cement on top to abandon Penn perfs.**
- 3) **Free point and attempt to cut 5-1/2" casing @ 2000'. POOH lay down casing**
- 4) **Spot 150' cement plug half-in and half-out @ 2000'. Tag.**
- 5) **Spot 100' cement plug across 13-3/8" casing shoe @ 640'.**
- 6) **Spot 50' surface plug**
- 7) **Cut off well head**
Install dry hole marker and reclaim location.