•					
Submit 3 Copies To Appropriate District	State of New Mexico				Form C-103
Office District 1	Energy, Minerals and Natural Resources			Revised June 10, 2003	
1625 N. French Dr., Hobbs, NM 88240				WELL API NO.	
<u>District II</u> 1301 W. Grand Ave., Artesia, NM 88210	OIL CONSERVATION DIVISION			30-015-32799	CT
District III	1220 South St. Francis Dr.			5. Indicate Type	
1000 Rio Brazos Rd., Aztec, NM 87410	Santa Fe, NM 87505			STATE 6. State Oil & G	FEE
<u>District IV</u> 1220 S. St. Francis Dr., Santa Fe, NM	54114 1 C, 1 11 1 0 1 5 0 5			o. State Off & G	as Lease No.
87505					
SUNDRY NOTICES AND REPORTS ON WELLS				7. Lease Name or Unit Agreement Name	
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH				Tesuque 2 State	
PROPOSALS.)	,			8. Well Number	
1. Type of Well:	Other RECEIVEL			1	
	Other			0 OCDIDAY 1	
2. Name of Operator SEP 2 3 2005				9. OGRID Number	
Devon Energy Production Company, LP 3. Address of Operator				6137 10. Pool name or Wildcat	
3. Address of Operator 20 North Broadway, Suite 1500, Oklahoma City, Oklahoma 73102				Brushy Draw Delaware North	
4. Well Location				Drusiny Blaw Be	iawaro ryotti
W W Zoomion					
Unit LetterC:_660'	feet from the _	North	line and19	80'feet from	theWestline
Section 2 Township 26S Range 29E Eddy County					
	11. Elevation (Show wh	hether DR,	RKB, RT, GR, etc.)		
	2997' GR	1' . NT	CNI	D / 0/1	
12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:					
PERFORM REMEDIAL WORK	PLUG AND ABANDON	1 🗵	REMEDIAL WORI	K L	ALTERING CASING
TEMPORARILY ABANDON	CHANGE PLANS		COMMENCE DRI	LLING OPNS.	PLUG AND
PULL OR ALTER CASING	MULTIPLE		CASING TEST AN	ın []	ABANDONMENT
	COMPLETION		CEMENT JOB	ND []	
	22				
OTHER:			OTHER:		
13. Describe proposed or complete					
of starting any proposed work	:). SEE RULE 1103. F	For Multip	le Completions: Att	tach wellbore diagi	ram of proposed completion
or recompletion.					
1 Set CIDD at 5221' Dumn 25' same	ent on ton Too TOC				
 Set CIBP at 5231'. Dump 35' ceme Circulate hole with 9 ppg mud. 	in on top. Tag TOC.				
3. Spot 150' cement plug from 2800' t	o 2950'. WOC & Tag.				
4. Spot 100' cement plug from 531' to			ng shoe at 581')		
5. Circulate cement plug from 60' to surface.					
6. Cut wellhead off 3' BGL & set dry 1		ation.			
I hereby certify that the information ab	ove is true and comple	te to the be	est of my knowledge	e and belief.	
SIGNATURE Rome Stack TITLE: Engineering Technician DATE 9/21/05					
Type or print name Ronnie Slack E-mail address: Ronnie.Slack@dvn.com Telephone No. 405-552-4615					
(This space for State use)					
M. H.	E. b	/	1.01		9/1-/-
APPPROVED BY 1	yu	TITLE_	en ay.		DATE 1/ 1/ 0)
Conditions of approval, if any:					, ,
			π.⊘. • •		• • •

Noilfy OCD 24 hrs . prior to any work done.

If this work requires an earthen pit, a permit must be approved <u>prior</u> to construction of the pit(s).

