RECEIVED

Form 3160-5 (June 2015)

JUDE PAR ZMENT OF THE INTERIOR

FORM APPROVED OMB NO. 1004-0137

RI	UREAU OF LAND MANAGE	MENT		January 31, 2018
SUNDRY, NOTICES AND REPORTS ON WELLS Dolling disc this form for proposals to drill or to re-enter an abandoned well. Use form 3160-3 (APD) for such proposals.			5. Lease Serial No. NMNM89172	•
			6. If Indian, Allottee	or Tribe Name
SUBMIŢ IN T	TRIPLICATE - Other instruc	ctions on page 2	7. If Unit or CA/Agr	reement, Name and/or No.
1. Type of Well	8. Well Name and N MultipleSee At			
		DALLE CHARMAN		
OXY USA INCORPORATED	RAH E CHAPMAN PMAN@OXY.COM	9. API Well No. MultipleSee	9. API well No. MultipleSee Attached	
3a. Address 5 GREENWAY PLAZA SUITE HOUSTON, TX 77046-0521	b. Phone No. (include area code) h: 713-350-4997		10. Field and Pool or Exploratory Area PURPLE SAGE-WOLFCAMP (GAS)	
4. Location of Well (Footage, Sec., T		11. County or Parish, State		
MultipleSee Attached			EDDY COUNT	ΓY, NM
12. CHECK THE AF	PPROPRIATE BOX(ES) TO	INDICATE NATURE OF	NOTICE, REPORT, OR OT	THER DATA
TYPE OF SUBMISSION		TYPE OF ACTION		
Notice of Intent	☐ Acidize	□ Deepen	☐ Production (Start/Resume)	☐ Water Shut-Off
_	☐ Alter Casing	☐ Hydraulic Fracturing	☐ Reclamation	☐ Well Integrity
☐ Subsequent Report	□ Casing Repair	■ New Construction	☐ Recomplete	Other,
☐ Final Abandonment Notice	☐ Change Plans	□ Plug and Abandon	□ Temporarily Abandon	Drilling Operations
	☐ Convert to Injection	☐ Plug Back	■ Water Disposal	
If the proposal is to deepen directions Attach the Bond under which the wor following completion of the involved testing has been completed. Final Attach the steen completed. Final Attach the site is ready for from the following 30-015-45112 - Sunrise MDP 30-015-45152 - Sunrise MDP 30-015-45153 - Sunrise MDP Please find the updated docur Thank you.	rk will be performed or provide the l operations. If the operation results bandonment Notices must be filed of inal inspection. quests the right to cement the gwells: 1 8-5 Federal Com 174H - NI 1 8-5 Federal Com 175H - NI 1 8-5 Federal Com 176H - NI mentation for more information.	Bond No. on file with BLM/BIA in a multiple completion or recomply after all requirements, including intermediate casing string MNM089172 MNM089172 MNM089172 MNM089172 Dn.	Required subsequent reports must be mpletion in a new interval, a Form 3 ng reclamation, have been completed.	pe filed within 30 days 160-4 must be filed once d and the operator has
Con	Electronic Submission #464	CORPORATED, sent to the ing by PRISCILLA PEREZ or	Carlsbad	
Signature (Electronic S	Submission)) Date 05/08/20		
	THIS SPACE FOR	FEDERAL OR STATE	OFFICE USE	
Approved By_NDUNGU KAMAU			JM ENGINEER	Date 05/21/2019
Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon.			<u> </u>	

Additional data for EC transaction #464496 that would not fit on the form

Wells/Facilities, continued

 Agreement NMNM89172
 Lease NMNM89172
 Well/Fac Name, Number SUNRISE MDP1 8-5 FEDERAL COM0-07/45-45112-00-X1
 Location Sec 17 T24S R31E NWNE 592FNL 1369FEL. 32.222969 N Lat, 103.795731 W Lon Sec 17 T24S R31E NWNE 592FNL 1334FEL. 32.222969 N Lat, 103.795616 W Lon

 NMNM89172
 NMNM89172
 SUNRISE MDP1 8-5 FEDERAL COM0-07/45-45153-00-X1
 Sec 17 T24S R31E NWNE 592FNL 1334FEL. 32.222969 N Lat, 103.795616 W Lon

 NMNM89172
 SUNRISE MDP1 8-5 FEDERAL COM0-07/45-45153-00-X1
 Sec 17 T24S R31E NENE 592FNL 1299FEL. 32.222969 N Lat, 103.795502 W Lon

Revisions to Operator-Submitted EC Data for Sundry Notice #464496

Operator Submitted

Sundry Type:

NOI

Lease:

NMNM89172

Agreement:

Operator:

OXY USA INC. P.O. BOX 4294 HOUSTON, TX 77210 Ph: 713-350-4997

Admin Contact:

SARAH E CHAPMAN REGULATORY SPECIALIST E-Mail: SARAH CHAPMAN@OXY.COM Cell: 281-642-5503 Ph: 713-350-4997

Tech Contact:

SARAH E CHAPMAN REGULATORY SPECIALIST E-Mail: SARAH CHAPMAN@OXY.COM Cell: 281-642-5503 Ph: 713-350-4997

Location:

State: County:

EDDY COUNTY

Field/Pool: Well/Facility:

SUNRISE MDP1 8-5 FEDERAL COM 174H Sec 17 T24S R31E NWNE 592FNL 1369FEL

32.222969 N Lat, 103.795731 W Lon

PURPLE SAGE-WOLFCAMP (GAS

BLM Revised (AFMSS)

DRG NOI

NMNM89172

OXY USA INCORPORATED 5 GREENWAY PLAZA SUITE 110 HOUSTON, TX 77046-0521

Ph: 713.350.4816

SARAH E CHAPMAN REGULATORY SPECIALIST E-Mail: SARAH CHAPMAN@OXY.COM Cell: 281-642-5503 Ph: 713-350-4997

SARAH E CHAPMAN REGULATORY SPECIALIST E-Mail: SARAH CHAPMAN@OXY.COM Cell: 281-642-5503 Ph: 713-350-4997

NM

EDDY

PURPLE SAGE-WOLFCAMP (GAS)

SUNRISE MDP1 8-5 FEDERAL COM 174H Sec 17 T24S R31E NWNE 592FNL 1369FEL 32.222969 N Lat, 103.795731 W Lon SUNRISE MDP1 8-5 FEDERAL COM 175H Sec 17 T24S R31E NWNE 592FNL 1334FEL

32.222969 N Lat, 103.795616 W Lon SUNRISE MDP1 8-5 FEDERAL COM 176H Sec 17 T24S R31E NENE 592FNL 1299FEL 32.222969 N Lat, 103.795502 W Lon

Offline Cementing

Oxy requests a variance to cement the 7.625" intermediate casing strings offline on the following wells, in accordance to the approved variance, EC Tran 461365:

API#	Well Name	Lease Serial #
30-015-45112	Sunrise MDP1 8-5 Federal Com 174H	NMNM089172
30-015-45152	Sunrise MDP1 8-5 Federal Com 175H	NMNM089172
30-015-45153	Sunrise MDP1 8-5 Federal Com 176H	NMNM089172

The summarized operational sequence will be as follows:

- 1. Run casing as per normal operations. While running casing, conduct negative pressure test and confirm integrity of the float equipment (float collar and shoe).
- 2. Land casing.
- 3. Fill pipe with kill weight fluid, and confirm well is static.
 - a. If well is not static notify BLM and kill well.
 - b. Once well is static notify BLM with intent to proceed with nipple down and offline cementing.
- 4. Set and pressure test annular packoff.
- 5. After confirmation of both annular barriers and internal barriers, nipple down BOP and install cap flange. If any barrier fails to test, the BOP stack will not be nippled down until after the cement job is completed.
- 6. Skid rig to next well on pad.
- 7. Confirm well is static before removing cap flange.
- 8. If well is not static notify BLM and kill well prior to cementing or nippling up for further remediation.
- 9. Install offline cement tool.
- 10. Rig up cement equipment.
 - a. Notify BLM prior to cement job.
- 11. Perform cement job.
- 12. Confirm well is static and floats are holding after cement job.
- 13. Remove cement equipment, offline cement tools and install night cap with pressure gauge for monitoring.