Submit 3 Copies To Appropriate District Office	State of New Mexico	Form C-103
District I	Energy, Minerals and Natural Resources	May 27, 2004
1625 N. French Dr. Hobbs, NM 88240 District II		WELL API NO.
1301 W. Grand Ave., Artesia, NM 88210	OIL CONSERVATION DIVISION	5 Indicate Type of Lease
District III	1220 South St. Francis Dr.	STATE FEE X
1000 Rio Brazos Rd., Aztec, NM 87410 District IV	Santa Fe, NM 87505	6 State Oil & Gas Lease No.
1220 S St. Francis Dr., Santa Fe, NM 87505	The state of the s	Sanc On te das Bease No.
(DO NOT USE THIS FORM FOR PROPOSA	ES AND REPORTS ON WELLS ALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A ATION FOR PERMIT" (FORM C-101) FOR SUCH	7 Lease Name or Unit Agreement Name Artesia Unit
· · · · · · · · · · · · · · · · · · ·	Well Other X	8. Well Number. 46
2 Name of Operator	JUN 0.9 2008	9. OGRID Number: 184860
Melrose Operating Company		10.5
3 Address of Operator c/o Box 953, Midland, TX 79702	OCD-ARTESIA	10. Pool name or Wildcat Artesia: Queen-Grayburg-San Andres
4 Well Location		
Unit Letter F :	feet from the North line and	feet from the West line
Section 3	Township 18S Range 28E	NMPM Eddy County
Mary Mary Company of the Company of	11 Elevation (Show whether DR, RKB, RT GR, et	
		The second secon
Pit or Below-grade Tank Application 🔲 or	(losure 🗌	
Pit type Depth to Groundwate	erDistance from nearest fresh water wellI	listance from neavest surface water
Pit Liner Thickness: mil	Below-Grade Tank: Volume hbls;	Construction Material
12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data		
NOTICE OF INT		BSEQUENT REPORT OF:
PERFORM REMEDIAL WORK	PLUG AND ABANDON REMEDIAL WO	ORK X ALTERING CASING
PERFORM REMEDIAL WORK TEMPORARILY ABANDON	PLUG AND ABANDON REMEDIAL WO	ORK X ALTERING CASING RILLING OPNS. □ P AND A □
PERFORM REMEDIAL WORK	PLUG AND ABANDON REMEDIAL WO	ORK X ALTERING CASING RILLING OPNS. □ P AND A □
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER:	PLUG AND ABANDON	ORK X ALTERING CASING RILLING OPNS. PAND A ONT JOB
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or complete of starting any proposed work	PLUG AND ABANDON	ORK X ALTERING CASING RILLING OPNS. PAND A D INT JOB and give pertinent dates, including estimated date
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or comple of starting any proposed work or recompletion.	PLUG AND ABANDON REMEDIAL WO CHANGE PLANS COMMENCE DE CASING/CEME CASING/CEME OTHER: sted operations. (Clearly state all pertinent details, k). SEE RULE 1103. For Multiple Completions:	RILLING OPNS. PAND A CASING PAND PAND A CASING PAND A CASING PAND A CASING PAND A CASING PAND PAND A CASING PAND PAND PAND PAND PAND PAND PAND PAND
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or comple of starting any proposed work or recompletion. 4-30-08: Rigged up Flowed well back. Re 5-1-08: Till w/packer & test RBP. Dumpe	PLUG AND ABANDON REMEDIAL WO CHANGE PLANS COMMENCE D COMMENCE D CASING/CEME OTHER: tied operations. (Clearly state all pertinent details, k). SEE RULE 1103. For Multiple Completions: clease Baker AD-1 packer. TOH. RIH & set RBP @ 1900 ad 2 sx sand. TiH to 1862', Halliburton pumped 25 sx Mi	RILLING OPNS. PAND A and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion completion. Page 1840-1850'.
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or comple of starting any proposed work or recompletion. 4-30-08: Rigged up Flowed well back. Re 5-1-08: Till w/packer & test RBP. Dumpe 300' cement in casing. Pulled up to 1400'.	PLUG AND ABANDON REMEDIAL WO CHANGE PLANS COMMENCE D CASING/CEME OTHER: tied operations. (Clearly state all pertinent details, k). SEE RULE 1103. For Multiple Completions: clease Baker AD-1 packer. TOH. RIH & set RBP @ 1900; dd 2 sx sand. TIH to 1862', Halliburton pumped 25 sx Mi. Closed BOP. Pressured up casing to 2000 psi bled to 1900.	RILLING OPNS. PAND A name of proposed completion of proposed complet
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or comple of starting any proposed work or recompletion. 4-30-08: Rigged up Flowed well back. Re 5-1-08: Till w/packer & test RBP. Dumpe 300' cement in casing. Pulled up to 1400'. 5-5-08: Till w/bit, tagged cement @ 1680	PLUG AND ABANDON REMEDIAL WO CHANGE PLANS COMMENCE D CASING/CEME OTHER: ted operations. (Clearly state all pertinent details, which is the completions: clease Baker AD-1 packer. TOH. RIH & set RBP @ 1900; ad 2 sx sand. TiH to 1862', Halliburton pumped 25 sx Mic. Closed BOP. Pressured up casing to 2000 psi bled to 1900; drilled out to 1875'. Closed BOP & pressure test to 50	RILLING OPNS. PAND A name of proposed completion of proposed complet
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or complet of starting any proposed work or recompletion. 4-30-08: Rigged up Flowed well back. Reference of the starting and the sta	PLUG AND ABANDON REMEDIAL WO CHANGE PLANS COMMENCE D CASING/CEME OTHER: ted operations. (Clearly state all pertinent details, which is to the completions: Stease Baker AD-1 packer. TOH. RIH & set RBP @ 1900; ad 2 sx sand. TiH to 1862', Halliburton pumped 25 sx Mic. Closed BOP. Pressured up casing to 2000 psi bled to 1900; drilled out to 1875'. Closed BOP & pressure test to 50 overshot for RBP. Milling.	RILLING OPNS. PAND A name of proposed completion of proposed complet
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or comple of starting any proposed work or recompletion. 4-30-08: Rigged up Flowed well back. Refore the starting and proposed work of the starting a	PLUG AND ABANDON REMEDIAL WO CHANGE PLANS COMMENCE D CASING/CEME DOTHER: Sted operations. (Clearly state all pertinent details, which is the completions: Clease Baker AD-1 packer. TOH. RIH & set RBP @ 1900 and 2 sx sand. TIH to 1862', Halliburton pumped 25 sx Mi. Closed BOP. Pressured up casing to 2000 psi bled to 1900 and the completions of the completions of the completion of the completions. Closed BOP. Pressured up casing to 2000 psi bled to 1900 and the completion of the completion o	RILLING OPNS. PAND A mand give pertinent dates, including estimated date Attach wellbore diagram of proposed completion croMatrix cement. Spot across perfs @ 1840-1850°. On psi & held after 30 minutes. Will shut in till 5/5/08 psi, would not hold.
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or comple of starting any proposed work or recompletion. 4-30-08: Rigged up Flowed well back. Re 5-1-08: Till w/packer & test RBP. Dumpe 300' cement in casing. Pulled up to 1400' 5-5-08: Till w/bit, tagged cement @ 1680 5-6-08: Till w/s sand off RBP, pick up of 5-7-08: Milled across perfs from 1900-180 5-9-08: Till w/5 1/2" casing patch & settur 5-10-08: Till w/AD-1 coated packer & 2.2	PLUG AND ABANDON REMEDIAL WO CHANGE PLANS COMMENCE D CASING/CEME MULTIPLE COMPL CASING/CEME OTHER: ted operations. (Clearly state all pertinent details, which is the completions: clease Baker AD-1 packer. TOH. RIH & set RBP @ 1900 ad 2 sx sand. TIH to 1862', Halliburton pumped 25 sx Mid. Closed BOP. Pressured up casing to 2000 psi bled to 1800', drilled out to 1875'. Closed BOP & pressure test to 50 overshot for RBP. Milling. DO'. TOH w/string mill.	RILLING OPNS. PAND A mand give pertinent dates, including estimated date Attach wellbore diagram of proposed completion croMatrix cement. Spot across perfs @ 1840-1850°. On psi & held after 30 minutes. Will shut in till 5/5/08 psi, would not hold.
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or comple of starting any proposed work or recompletion. 4-30-08: Rigged up Flowed well back. Re 5-1-08: Tilh w/packer & test RBP. Dumpe 300° cement in casing. Pulled up to 1400° 5-5-08: Tilh w/bit, tagged cement @ 1680 5-6-08: Tilh w/si, tagged cement @ 1680 5-7-08: Milled across perfs from 1900-180 5-9-08: Tilh w/5 1/2° casing patch & setter 5-10-08: Tilh w/AD-1 coated packer & 2 2 and cleaned location	PLUG AND ABANDON REMEDIAL WO CHANGE PLANS COMMENCE D CASING/CEME DOTHER: Sted operations. (Clearly state all pertinent details, which is the completions: Clease Baker AD-1 packer. TOH. RIH & set RBP @ 1900 and 2 sx sand. TIH to 1862', Halliburton pumped 25 sx Mi. Closed BOP. Pressured up casing to 2000 psi bled to 1900 and the completions of the completions of the completion of the completions. Closed BOP. Pressured up casing to 2000 psi bled to 1900 and the completion of the completion o	RILLING OPNS. PAND A mand give pertinent dates, including estimated date Attach wellbore diagram of proposed completion croMatrix cement. Spot across perfs @ 1840-1850°. On psi & held after 30 minutes. Will shut in till 5/5/08 psi, would not hold.
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or comple of starting any proposed work or recompletion. 4-30-08: Rigged up Flowed well back. Re 5-1-08: Till w/packer & test RBP. Dumpe 300' cement in casing. Pulled up to 1400' 5-5-08: Till w/bit, tagged cement @ 1680 5-6-08: Till w/s sand off RBP, pick up of 5-7-08: Milled across perfs from 1900-180 5-9-08: Till w/5 1/2" casing patch & settur 5-10-08: Till w/AD-1 coated packer & 2.2	PLUG AND ABANDON REMEDIAL WO CHANGE PLANS COMMENCE D CASING/CEME DOTHER: Sted operations. (Clearly state all pertinent details, which is the completions: Clease Baker AD-1 packer. TOH. RIH & set RBP @ 1900 and 2 sx sand. TIH to 1862', Halliburton pumped 25 sx Mi. Closed BOP. Pressured up casing to 2000 psi bled to 1900 and the completions of the completions of the completion of the completions. Closed BOP. Pressured up casing to 2000 psi bled to 1900 and the completion of the completion o	RILLING OPNS. PAND A mand give pertinent dates, including estimated date Attach wellbore diagram of proposed completion croMatrix cement. Spot across perfs @ 1840-1850°. On psi & held after 30 minutes. Will shut in till 5/5/08 psi, would not hold.
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or comple of starting any proposed work or recompletion. 4-30-08: Rigged up Flowed well back. Re 5-1-08: Till w/packer & test RBP. Dumpe 300' cement in casing. Pulled up to 1400'. 5-5-08: Till w/bit, tagged cement @ 1680 5-6-08: Till w/sh sand off RBP, pick up of 5-7-08: Milled across perfs from 1900-180 5-9-08: Till w/5 1/2" casing patch & settur 5-10-08: Till w/AD-1 coated packer & 2 and cleaned location Work performed to comply with WFX.	PLUG AND ABANDON CHANGE PLANS COMMENCE DE COMMENCE DE CASING/CEME COMMENCE DE CASING/CEME CHANGE PLANS COMMENCE DE CASING/CEME COMMENCE DE CASING/CEME COMMENCE DE CASING/CEME COMMENCE DE CASING/CEME COMMENCE DE COMME	RILLING OPNS. PAND A and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion completion by the completion of proposed
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or comple of starting any proposed work or recompletion. 4-30-08: Rigged up Flowed well back. Re 5-1-08: Till w/packer & test RBP. Dumpe 300' cement in casing. Pulled up to 1400'. 5-5-08: Till w/bit, tagged cement @ 1680 5-6-08: Till w/sh sand off RBP, pick up of 5-7-08: Milled across perfs from 1900-180 5-9-08: Till w/5 1/2" casing patch & settur 5-10-08: Till w/AD-1 coated packer & 2 and cleaned location Work performed to comply with WFX.	PLUG AND ABANDON REMEDIAL WO CHANGE PLANS COMMENCE DE COMMENCE DE CHANGE PLANS COMMENCE DE CASING/CEME DE CASIN	RILLING OPNS. PAND A and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion completion by the completion of proposed
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or comple of starting any proposed work or recompletion. 4-30-08: Rigged up Flowed well back. Re 5-1-08: Till w/packer & test RBP. Dumpe 300' cement in casing. Pulled up to 1400'. 5-5-08: Till w/bit, tagged cement @ 1680 5-6-08: Till w/sh sand off RBP, pick up of 5-7-08: Milled across perfs from 1900-180 5-9-08: Till w/5 1/2" casing patch & setter 5-10-08: Till w/5 1/2" casing patch & setter 5-10-08: Till w/AD-1 coated packer & 2 and cleaned location Work performed to comply with WFX. I hereby certify that the information al grade tank has been/will be constructed or estimated.	PLUG AND ABANDON REMEDIAL WO CHANGE PLANS COMMENCE DE COMMENCE DE CHANGE PLANS COMMENCE DE	RILLING OPNS. PAND A and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion of proposed plan of pro
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or comple of starting any proposed work or recompletion. 4-30-08: Rigged up Flowed well back. Re 5-1-08: Till w/packer & test RBP. Dumpe 300' cement in casing. Pulled up to 1400'. 5-5-08: Till w/bit, tagged cement @ 1680 5-6-08: Till w/sh sand off RBP, pick up of 5-7-08: Milled across perfs from 1900-180 5-9-08: Till w/5 1/2" casing patch & setter 5-10-08: Till w/5 1/2" casing patch & setter 5-10-08: Till w/AD-1 coated packer & 2 and cleaned location Work performed to comply with WFX. I hereby certify that the information al grade tank has been/will be constructed or estimated.	PLUG AND ABANDON REMEDIAL WO CHANGE PLANS COMMENCE DE COMMENCE DE CHANGE PLANS COMMENCE DE CASING/CEME DE CASIN	RILLING OPNS. PAND A and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion of proposed plan of pro
PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or comple of starting any proposed work or recompletion. 4-30-08: Rigged up Flowed well back. Re 5-1-08: Till w/packer & test RBP. Dumpe 300' cement in casing. Pulled up to 1400'. 5-5-08: Till w/bit, tagged cement @ 1680 5-6-08: Till w/sh sand off RBP, pick up o 5-7-08: Milled across perfs from 1900-180 5-9-08: Till w/5 1/2" casing patch & setter 5-10-08: Till w/5 1/2" casing patch & setter 5-10-08: Till w/AD-1 coated packer & 2 and cleaned location Work performed to comply with WFX. I hereby certify that the information al grade tank has been/will be constructed or estimated to possible tank has been/will be constructed or estimated to possible tank has been/will be constructed or estimated to possible tank has been/will be constructed or estimated to possible tank has been/will be constructed or estimated to possible tank has been/will be constructed or estimated tank has been/will be constructed or estimated to the constructed or estimated tank has been/will be constructed tank has been/will be constructed to tank has been/will be constru	PLUG AND ABANDON REMEDIAL WO CHANGE PLANS COMMENCE DE COMMENCE DE CHANGE PLANS COMMENCE DE COMENCE DE COMMENCE DE C	RILLING OPNS. PAND A and give pertinent dates, including estimated date Attach wellbore diagram of proposed completion of proposed plan of pro