
Office	o Appropriate District		New Me			Form C-103 May 27, 2004
District I Energy, Minerals and Natural Resources 1625 N French Dr , Hobbs, NM 88240			WELL API NO.	30-005-62696		
District II	e, Artesia, NM 88210	OIL CONSER 1220 Sout			5. Indicate Type of STATE x	Lease FEE
1000 Rio Brazos R	d , Aztec, NM 87410		ii St. 11aii e, NM 87		6. State Oil & Gas I	
	Dr., Santa Fe, NM	Santa 1	C, 141VI 07	303	LG 667	77
SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS)					7. Lease Name or Unit Agreement Name West of Eden Unit	
1. Type of Well: Oil Well Gas Well X Other					8. Well Number	1
2 Name of Owner to				2 0 2008	9. OGRID Number	255333
Heritage Plaza, 1111 Bagby St. Suite 4600, Houston, TX 77002				ARTESIA	10. Pool name or W West Pecos S	į.
4. Well Locati						
		660feet from the				
Sectio	n 14	Township 11. Elevation (Show w				Chaves County
		3,	,867.5' GR	KKB, KI, GK, etc.,		
Pit or Below-grade	Tank Application 🔲 o					
Pit type		aterDistance from ne				e water
Pit Liner Thicknes						- And Annual Control of the Annual Control o
	12. Check A	Appropriate Box to It	ndicate Na	ature of Notice,	Report or Other D	ata
		PLUG AND ABANDON	N	REMEDIAL WOR	ILLING OPNS. P	ORT OF: LTERING CASING ☐ AND A X
					<u> </u>	
OTHER:				OTHER:	_	П
					d give pertinent dates,	including estimated date
13. Describ				ertinent details, an	d give pertinent dates,	including estimated date n of proposed completion
13. Describ	ng any proposed wo	ork). SEE RULE 1103.		ertinent details, an	d give pertinent dates,	
13. Describ of starti or recor	ing any proposed wo mpletion. MOVE IN EQUIP FLOW DOWN W	ork). SEE RULE 1103.	For Multipl F BRINE T	pertinent details, an e Completions: At	d give pertinent dates, ttach wellbore diagram	
13. Describ of starti or recoi 6/5/2008 6/8/2008	ng any proposed wo mpletion. MOVE IN EQUIP FLOW DOWN W BOLTS – ND WE	PMENT (ELL – PUMP LOAD O ELLHEAD – NU BOP – S	For Multipl F BRINE T SDFD	ertinent details, an e Completions: At O KILL WELL –	d give pertinent dates, ttach wellbore diagram	n of proposed completion ABLE GAS – CUT OFF
13. Describ of starti or recor	ing any proposed wo mpletion. MOVE IN EQUIP FLOW DOWN W BOLTS – ND WE KILL WELL – P.	PMENT PELL – PUMP LOAD O' CLLHEAD – NU BOP – S ACKER STUCK – RIH	For Multipl F BRINE T SDFD AND CUT	ertinent details, an e Completions: At TO KILL WELL – F TUBING @ PA	d give pertinent dates, ttach wellbore diagram SNIFF FOR FLAMM CKER – POH WITH	n of proposed completion
13. Describ of starti or recor 6/5/2008 6/8/2008 6/9/2008	mg any proposed wompletion. MOVE IN EQUIP FLOW DOWN W BOLTS – ND WE KILL WELL – P, CIBP TO 2948' – @ 2948' – POH ~	ORK). SEE RULE 1103. PMENT PELL – PUMP LOAD OF ELLHEAD – NU BOP – S ACKER STUCK – RIH POH – RIH WITH TUE RIH AND PERF @1086	For Multipl F BRINE T SDFD I AND CUT BING – TA 6' – PIH WI	FO KILL WELL – T TUBING @ PA G CIBP – CIRCU	d give pertinent dates, ttach wellbore diagram SNIFF FOR FLAMM CKER – POH WITH LATE PLUGGING M UMP 80 SACKS - PC	ABLE GAS – CUT OFF TUBING – RIH WITH TUD – SPOT 25 SACKS OH – WOC – SDFD
13. Describ of starti or recoi 6/5/2008 6/8/2008	mg any proposed wompletion. MOVE IN EQUIP FLOW DOWN W BOLTS – ND WE KILL WELL – P. CIBP TO 2948' – @ 2948' – POH – RIH AND TAG (ork). SEE RULE 1103. PMENT PELL – PUMP LOAD OF ELLHEAD – NU BOP – S ACKER STUCK – RIH POH – RIH WITH TUE RIH AND PERF @1086 @ 806' – SPOT 15 SAC	For Multipl F BRINE T SDFD (AND CUT BING – TA 6' – PIH WI CKS ON TO	FO KILL WELL – TO KILL WELL – TO TUBING @ PA TO CIBP – CIRCU TO PER PHIL HA	d give pertinent dates, ttach wellbore diagram SNIFF FOR FLAMM CKER – POH WITH LATE PLUGGING M UMP 80 SACKS - PC	ABLE GAS – CUT OFF TUBING – RIH WITH TUD – SPOT 25 SACKS OH – WOC – SDFD IH AND PERF @ 60' –
13. Describ of starti or recor 6/5/2008 6/8/2008 6/9/2008	ing any proposed wompletion. MOVE IN EQUIP FLOW DOWN W BOLTS – ND WE KILL WELL – P. CIBP TO 2948' – @ 2948' – POH – RIH AND TAG (CIRCULATE 25.5)	ork). SEE RULE 1103. PMENT PELL – PUMP LOAD OF ELLHEAD – NU BOP – S ACKER STUCK – RIH POH – RIH WITH TUE RIH AND PERF @1086 @ 806' – SPOT 15 SAC	For Multipl F BRINE T SDFD I AND CUT BING – TA 6' – PIH WI CKS ON TO – RIG DOV	FOR KILL WELL — TO KILL WELL — TO TUBING @ PA GOORD — CIRCU TO PACKER — PO OP PER PHIL HAWN — DIG OUT W	d give pertinent dates, trach wellbore diagram SNIFF FOR FLAMM CKER – POH WITH LATE PLUGGING M UMP 80 SACKS - PO WKINS – POH – R /ELLHEAD – CUT O	ABLE GAS – CUT OFF TUBING – RIH WITH MUD – SPOT 25 SACKS OH – WOC – SDFD IH AND PERF @ 60' – OFF WELLHEAD – CUT
13. Describ of starti or recor 6/5/2008 6/8/2008 6/9/2008	ing any proposed wompletion. MOVE IN EQUIP FLOW DOWN W BOLTS – ND WE KILL WELL – P. CIBP TO 2948' – @ 2948' – POH – RIH AND TAG (CIRCULATE 25.5)	PMENT PELL – PUMP LOAD OF CLLHEAD – NU BOP – S ACKER STUCK – RIH POH – RIH WITH TUR RIH AND PERF @1086 @ 806' – SPOT 15 SAC SACKS TO SURFACE	For Multipl F BRINE T SDFD I AND CUT BING – TA 6' – PIH WI CKS ON TO – RIG DOV	FOR KILL WELL — TO KILL WELL — TO TUBING @ PA GOORD — CIRCU TO PACKER — PO OP PER PHIL HAWN — DIG OUT W	d give pertinent dates, trach wellbore diagram SNIFF FOR FLAMM CKER – POH WITH LATE PLUGGING M UMP 80 SACKS - PO WKINS – POH – R /ELLHEAD – CUT O	ABLE GAS – CUT OFF TUBING – RIH WITH MUD – SPOT 25 SACKS OH – WOC – SDFD IH AND PERF @ 60' – OFF WELLHEAD – CUT
13. Describ of starti or recor 6/5/2008 6/8/2008 6/9/2008	mg any proposed wompletion. MOVE IN EQUIP FLOW DOWN W BOLTS – ND WE KILL WELL – P. CIBP TO 2948' – @ 2948' – POH – RIH AND TAG GOFF ANCHORES	PMENT PELL – PUMP LOAD OF CLLHEAD – NU BOP – S ACKER STUCK – RIH POH – RIH WITH TUR RIH AND PERF @1086 @ 806' – SPOT 15 SAC SACKS TO SURFACE	For Multipl F BRINE T SDFD I AND CUT BING – TA 6' – PIH WI CKS ON TO – RIG DOV	FOR KILL WELL — TO KILL WELL — TO TUBING @ PA GOORD — CIRCU TO PACKER — PO OP PER PHIL HAWN — DIG OUT W	d give pertinent dates, trach wellbore diagram SNIFF FOR FLAMM CKER – POH WITH LATE PLUGGING M UMP 80 SACKS - PO WKINS – POH – R /ELLHEAD – CUT O	ABLE GAS – CUT OFF TUBING – RIH WITH MUD – SPOT 25 SACKS OH – WOC – SDFD IH AND PERF @ 60' – OFF WELLHEAD – CUT
13. Describ of starti or recor 6/5/2008 6/8/2008 6/9/2008	mg any proposed wompletion. MOVE IN EQUIP FLOW DOWN W BOLTS – ND WE KILL WELL – P. CIBP TO 2948' – @ 2948' – POH – RIH AND TAG GOFF ANCHORES	PMENT PELL – PUMP LOAD OF CLLHEAD – NU BOP – S ACKER STUCK – RIH POH – RIH WITH TUR RIH AND PERF @1086 @ 806' – SPOT 15 SAC SACKS TO SURFACE	For Multipl F BRINE T SDFD I AND CUT BING – TA 6' – PIH WI CKS ON TO – RIG DOV	FOR KILL WELL — TO KILL WELL — TO TUBING @ PA GOORD — CIRCU TO PACKER — PO OP PER PHIL HAWN — DIG OUT W	d give pertinent dates, trach wellbore diagram SNIFF FOR FLAMM CKER – POH WITH LATE PLUGGING M UMP 80 SACKS - PO WKINS – POH – R /ELLHEAD – CUT O	ABLE GAS – CUT OFF TUBING – RIH WITH MUD – SPOT 25 SACKS OH – WOC – SDFD IH AND PERF @ 60' – OFF WELLHEAD – CUT
13. Describ of starti or recor 6/5/2008 6/8/2008 6/9/2008	mg any proposed wompletion. MOVE IN EQUIP FLOW DOWN W BOLTS – ND WE KILL WELL – P. CIBP TO 2948' – @ 2948' – POH – RIH AND TAG GOFF ANCHORES	PMENT PELL – PUMP LOAD OF CLLHEAD – NU BOP – S ACKER STUCK – RIH POH – RIH WITH TUR RIH AND PERF @1086 @ 806' – SPOT 15 SAC SACKS TO SURFACE	For Multipl F BRINE T SDFD I AND CUT BING – TA 6' – PIH WI CKS ON TO – RIG DOV	FOR KILL WELL — TO KILL WELL — TO TUBING @ PA GOORD — CIRCU TO PACKER — PO OP PER PHIL HAWN — DIG OUT W	d give pertinent dates, trach wellbore diagram SNIFF FOR FLAMM CKER – POH WITH LATE PLUGGING M UMP 80 SACKS - PO WKINS – POH – R /ELLHEAD – CUT O	ABLE GAS – CUT OFF TUBING – RIH WITH MUD – SPOT 25 SACKS OH – WOC – SDFD IH AND PERF @ 60' – OFF WELLHEAD – CUT
13. Describ of starti or recoil 6/5/2008 6/8/2008 6/9/2008 6/10/2008	ing any proposed wompletion. MOVE IN EQUIP FLOW DOWN WE BOLTS – ND WE KILL WELL – P. CIBP TO 2948' – @ 2948' – POH – RIH AND TAG (CIRCULATE 25 SOFF ANCHORES WELL P&A'd.	PMENT PMENT PELL – PUMP LOAD OF ELLHEAD – NU BOP – S ACKER STUCK – RIH POH – RIH WITH TUE RIH AND PERF @1086 @ 806' – SPOT 15 SAC SACKS TO SURFACE S – INSTALL DRYHOLI	FOR Multipl F BRINE T SDFD I AND CUT BING – TA 6' – PIH WI CKS ON TO – RIG DOV E MARKER	Pertinent details, an e Completions: At e Completions: At E TUBING @ PAR G CIBP - CIRCUITH PACKER - PU OP PER PHIL HAVN - DIG OUT WER - LEVEL LOCA	d give pertinent dates, ttach wellbore diagram SNIFF FOR FLAMM CKER – POH WITH LATE PLUGGING M UMP 80 SACKS - PC AWKINS – POH – R VELLHEAD – CUT O TION – CLEAN UP I	ABLE GAS – CUT OFF TUBING – RIH WITH MUD – SPOT 25 SACKS OH – WOC – SDFD IH AND PERF @ 60' – OFF WELLHEAD – CUT LOCATION – SDFD
13. Describ of starti or record 6/5/2008 6/8/2008 6/9/2008 6/10/2008	mg any proposed wompletion. MOVE IN EQUIP FLOW DOWN W BOLTS – ND WE KILL WELL – P. CIBP TO 2948' – @ 2948' – POH – RIH AND TAG (CIRCULATE 25 SOFF ANCHORES WELL P&A'd.	PMENT PELL – PUMP LOAD OF CLLHEAD – NU BOP – S ACKER STUCK – RIH POH – RIH WITH TUR RIH AND PERF @1086 @ 806' – SPOT 15 SAC SACKS TO SURFACE	F BRINE T SDFD AND CUT BING – TA 6' – PIH WI CKS ON TO – RIG DOV E MARKER	TO KILL WELL — TO KILL WELL — TO KILL WELL — TO TUBING @ PA TO TUBING WELL TO TUBING TUBING TO TUBING TO TUBING	d give pertinent dates, trach wellbore diagram SNIFF FOR FLAMM CKER – POH WITH LATE PLUGGING M UMP 80 SACKS - PC AWKINS – POH – RO VELLHEAD – CUT O TION – CLEAN UP I	ABLE GAS – CUT OFF TUBING – RIH WITH MUD – SPOT 25 SACKS OH – WOC – SDFD IH AND PERF @ 60' – OFF WELLHEAD – CUT LOCATION – SDFD
13. Describ of starti or record 6/5/2008 6/8/2008 6/9/2008 6/10/2008	mg any proposed wompletion. MOVE IN EQUIP FLOW DOWN W BOLTS – ND WE KILL WELL – P. CIBP TO 2948' – @ 2948' – POH – RIH AND TAG (CIRCULATE 25 SOFF ANCHORES WELL P&A'd.	PMENT PMENT PELL – PUMP LOAD OF CLLHEAD – NU BOP – S ACKER STUCK – RIH POH – RIH WITH TUE RIH AND PERF @1086 @ 806' – SPOT 15 SAC SACKS TO SURFACE S – INSTALL DRYHOLE	FOR Multiple F BRINE T SDFD AND CUT BING - TA 6' - PIH WI CKS ON TO - RIG DOV E MARKER	TO KILL WELL — TO KILL WELL — TO KILL WELL — TO TUBING @ PA TO TUBING WELL TO TUBING TUBING TO TUBING TO TUBING	d give pertinent dates, ttach wellbore diagram SNIFF FOR FLAMM CKER - POH WITH LATE PLUGGING M UMP 80 SACKS - PC AWKINS - POH - RO VELLHEAD - CUT O TION - CLEAN UP I Ge and belief. I further of an (attached) alternation	ABLE GAS – CUT OFF TUBING – RIH WITH MUD – SPOT 25 SACKS OH – WOC – SDFD IH AND PERF @ 60' – OFF WELLHEAD – CUT LOCATION – SDFD
13. Describ of starti or record 6/5/2008 6/8/2008 6/9/2008 6/10/2008 I hereby certify the grade tank has been SIGNATURE	mg any proposed wompletion. MOVE IN EQUIP FLOW DOWN W BOLTS – ND WE KILL WELL – P. CIBP TO 2948' – @ 2948' – POH – RIH AND TAG (CIRCULATE 25'S OFF ANCHORES WELL P&A'd.	PMENT PELL – PUMP LOAD OF PLLHEAD – NU BOP – S ACKER STUCK – RIH POH – RIH WITH TUF RIH AND PERF @1086 @ 806' – SPOT 15 SAC SACKS TO SURFACE – S – INSTALL DRYHOLI above is true and comple closed according to NMOCD	F BRINE T SDFD I AND CUT BING - TA 6' - PIH WI CKS ON TO - RIG DOV E MARKER	EST OF MY KNOWLED BY A GENERAL BUTCH PACKER — PURCH PACKER P	d give pertinent dates, ttach wellbore diagram SNIFF FOR FLAMM CKER - POH WITH LATE PLUGGING M UMP 80 SACKS - PC AWKINS - POH - RO VELLHEAD - CUT O TION - CLEAN UP I Ge and belief. I further of an (attached) alternation	TABLE GAS — CUT OFF TUBING — RIH WITH MUD — SPOT 25 SACKS OH — WOC — SDFD IH AND PERF @ 60' — OFF WELLHEAD — CUT LOCATION — SDFD certify that any pit or below- ve OCD-approved plan □. 16 June 2008
13. Describ of starti or record 6/5/2008 6/8/2008 6/9/2008 6/10/2008 I hereby certify the grade tank has been SIGNATURE	mpletion. MOVE IN EQUIP FLOW DOWN W BOLTS – ND WE KILL WELL – P. CIBP TO 2948' – @ 2948' – POH – RIH AND TAG (CIRCULATE 25 SOFF ANCHORES WELL P&A'd.	PMENT PELL – PUMP LOAD OF ELLHEAD – NU BOP – S ACKER STUCK – RIH POH – RIH WITH TUE RIH AND PERF @1086 @ 806' – SPOT 15 SAC SACKS TO SURFACE S – INSTALL DRYHOLE above is true and comple closed according to NMOCD	FOR Multiple F BRINE T SDFD I AND CUT BING - TA 6' - PIH WI CKS ON TO - RIG DOV E MARKER ete to the be guidelines TITLE: _ tmiller@li	TO KILL WELL — TO KILL WELL MELL WELL MELL WELL — TO KILL WELL WELL WELL MELL WELL WELL WELL WE	d give pertinent dates, ttach wellbore diagram SNIFF FOR FLAMM CKER - POH WITH LATE PLUGGING M UMP 80 SACKS - POH AWKINS - POH - R VELLHEAD - CUT O TION - CLEAN UP I To an (attached) alternation or an (attached) alternation of the control	TABLE GAS — CUT OFF TUBING — RIH WITH MUD — SPOT 25 SACKS OH — WOC — SDFD IH AND PERF @ 60' — OFF WELLHEAD — CUT LOCATION — SDFD certify that any pit or below- ve OCD-approved plan □. 16 June 2008
13. Describ of starti or record 6/5/2008 6/8/2008 6/9/2008 6/9/2008 I hereby certify the grade tank has been SIGNATURE Type or print nate For State Use Control of Starte	mg any proposed wompletion. MOVE IN EQUIP FLOW DOWN W BOLTS – ND WE KILL WELL – P. CIBP TO 2948' – @ 2948' – POH – RIH AND TAG (CIRCULATE 25' OFF ANCHORES WELL P&A'd. Chat the information n/will be constructed or me C. Tim Mille Only	PMENT PELL – PUMP LOAD OF PLLHEAD – NU BOP – S ACKER STUCK – RIH POH – RIH WITH TUF RIH AND PERF @1086 @ 806' – SPOT 15 SAC SACKS TO SURFACE – S – INSTALL DRYHOLI above is true and comple closed according to NMOCD	FOR Multiple F BRINE T SDFD I AND CUT BING - TA 6' - PIH WI CKS ON TO - RIG DOV E MARKER ete to the be guidelines TITLE: _ tmiller@li	TUBING @ PA G CIBP - CIRCU TH PACKER - PI OP PER PHIL HA WN - DIG OUT W R - LEVEL LOCA St of my knowledg J, a general permit Vice President Open Approved for plugging Lightly minder bond in	d give pertinent dates, trach wellbore diagram SNIFF FOR FLAMM CKER - POH WITH LATE PLUGGING M UMP 80 SACKS - POH AWKINS - POH - R VELLHEAD - CUT O TION - CLEAN UP I TO an (attached) alternation erations DATE: gof well bore only. a retained pending receipt	TABLE GAS — CUT OFF TUBING — RIH WITH MUD — SPOT 25 SACKS OH — WOC — SDFD IH AND PERF @ 60' — OFF WELLHEAD — CUT LOCATION — SDFD certify that any pit or below- ve OCD-approved plan 16 June 2008 (713) 292-9514
13. Describ of starti or record 6/5/2008 6/8/2008 6/9/2008 6/10/2008 I hereby certify the grade tank has been SIGNATURE	mg any proposed wompletion. MOVE IN EQUIP FLOW DOWN W BOLTS – ND WE KILL WELL – P. CIBP TO 2948' – @ 2948' – POH – RIH AND TAG (CIRCULATE 25' OFF ANCHORES WELL P&A'd. Chat the information n/will be constructed or me C. Tim Mille Only	PMENT PELL – PUMP LOAD OF ELLHEAD – NU BOP – S ACKER STUCK – RIH POH – RIH WITH TUE RIH AND PERF @1086 @ 806' – SPOT 15 SAC SACKS TO SURFACE S – INSTALL DRYHOLE above is true and comple closed according to NMOCD	FOR Multiple F BRINE T SDFD I AND CUT BING - TA 6' - PIH WI CKS ON TO - RIG DOV E MARKEF	TUBING @ PA G CIBP - CIRCU ITH PACKER - PI OP PER PHIL HA WN - DIG OUT W R - LEVEL LOCA St of my knowledg I, a general permit Vice President Ope imerockresources. Approved for plugging Liability under bond i of C:103 (Subsequent	d give pertinent dates, trach wellbore diagram SNIFF FOR FLAMM CKER — POH WITH LATE PLUGGING M UMP 80 SACKS - PO AWKINS — POH — R /ELLHEAD — CUT O TION — CLEAN UP I ce and belief. I further of an (attached) alternation erations DATE: gof well bore only. s retained pending receipt Report of Well Plugging) [In OCD Web Page under	TABLE GAS — CUT OFF TUBING — RIH WITH MUD — SPOT 25 SACKS OH — WOC — SDFD IH AND PERF @ 60' — OFF WELLHEAD — CUT LOCATION — SDFD certify that any pit or below- ve OCD-approved plan 16 June 2008 (713) 292-9514





Perforated @ 60' – Circulate 25 sx Cement to Surface

FINAL ABANDONMENT

15 sx Cement Plug on Top of 80 sx Plug

8-5/8", 24#, J-55, ST&C Casing @ 1,028'

Perforated @ 1,086' - Spot 80 sx Cement Plug from 1,086' to 806' (TAGGED)

TOC @ +/- 2,000'

25 sx Cement Plug

Cast Iron Bridge Plug @ 2,948' (TAGGED)

Packer (Stuck - unable to release)

Abo Perfs: 2,998-04' & 3,015-17' (10 - 0.40" DIA holes)

Cement Retainer @ 3,134'

Abo **SQUEEZED** Perfs: 3,193-96'; 3,201-07'; 3,227-

34' & 3,241-42' (19 - 0.40" DIA holes)

4-1/2"; 9.5#; J-55; ST&C Casing @ 3,413'

TD @ 3,413'

PBTD @ 3,372'

Lime Rock Resources
West of Eden Unit 1
Sec 14N-7S-23E
Chaves County, NM
Updated: 16 June 2008 SJH