

Stevens Operating Co.
O' Brien C # 4
Sec.1-9-28-L

1. Spot a 40 sx. plug at 6781' WOC and tag plug.
2. Spot a 25 sx. plug at 5150' across DV Tool.
3. Spot a 30 sx. plug at 2000'.
4. Perforate at 300' and circulate cement to surface and leave 5 1/2 csg full.
5. Salt-Gel shall be placed between pluggs at 25 lb. per bbl. of brine water.
6. Clean and level location.