

2/5/96

Rapid Co Inc. Copeland state ^{TX} 1st
AC 31-10-27

10:00 AM Rigged up (set CIBP ^{615'} smaller) circ hole
clean getting ready to cut casing

11:00 AM Broke for dinner

11:30 AM Riggng up to cut casing

12:00 Noon cut casing 600'

12:10 PM. casing not free, casing parted at
surface (1ft below) went in with packer to
see if we could circ up back side,
pressured up to 850 lbs no luck

12:55 PM. recut casing at 400', pressured up to
800 lbs trying to circ up back side no luck
CAME out with packer

1:30 PM going in with tubing to CIBP &
Bring cement to surface

2:20 PM Pumped 4 1/2 sacks cement

2:35 PM laying tubing down

2:50 PM Topped off cement at surface