

30-005-60405

A-33-11-29

C. W. Trainer

White Ranch #4

* 10 sx surface Plug.

* 30sx cement Plug 404'-304'.

* 30sx cement Plug 2232'-2132' TAG

* 25sx cement Plug 3510'-3410'.

* 25sx cement Plug 5762'-5662'.

* 25sx cement Plug 6750'-6650'.

* 25sx cement Plug 50' in + 50' out 5 1/2" casing stub. TAG

* Freepoint cut & Pull 5 1/2" casing 6700'+.

* Circulate brine gel to surface.

* Run & set CIBP @ 8402' w/35' cement on Top CIBP.

X
= Perts - 8502'-35'.

Formation Tops

T. Yal11 - 851'.

T. Q - 1550'.

T. S.A. - 2110'.

T. Glorieta - 3460'.

T. Abo - 5712'.

T. Wolfcamp - 6700'.

T. Miss. - 8312'.

Well History

13 3/8" casing - 354' w/350sx cement. circ.

8 5/8" casing - 2182' w/1200 sx cement. circ.

5 1/2" casing - 8850' w/2001x cl. H. cement.

T.O.C. - 7960' by Temp. Survey.