

7- 23-79

0- 4-10-29 Planet Inc Whittenburg C[#]1 Plug to Abandon
Set 35 SX @ TD 3049 to 2949 Fill hole with mud

7- 24-79

Cut 5 1/2 @ 2180 Pull and Lay down Ran Tubing to
2230 and Ran 35 SX Cement 2230 to 2130

Set 35 SX Plug @ 1775 to 1675

Set 35 SX Plug @ 640 and Let Set over Nite

7-25-79

Tagged Cement Plug @ 512 ft Set Surface Plug
and Install marker

Witness By BWV