

**District I**  
1625 N. French Dr., Hobbs, NM 88240

**District II**  
811 South First, Artesia, NM 88210

**District III**  
1000 Rio Brazos Rd., Aztec, NM 87410

**District IV**  
1220 S. St. Francis Dr., Santa Fe, NM  
87505

**OIL CONSERVATION DIVISION**  
1220 South St. Francis Dr.  
Santa Fe, NM 87505

Form C-103  
Revised March 25, 1999

### Cassidy AVF State

3601' GR

## OTHER:

1. Notify the NMOCD 24 hrs before starting the work to plug the well. Release the packer at 2184'. Circulate the well with 10.0 ppg brine plugging mud with 25 lbs of gel/bbl of mud then spot cement plug in the casing from ~~2184' to 1950'~~ then pull the tubing up to 1250' and spot a 20 sx cement plug in the casing from 1250' to 950', wait 3 hrs and tag the plug then pull the tubing to 300' and set a plug to the surface. *2250 ft  
100' of cmf  
N: out of  
CSS  
2150-22  
TAG*
2. ND the BOP and remove the wellhead and install a dry-hole marker and clean up the location. *Perf CSS @ 310  
Circ cmf to surface*

DATE JAN 27 2003