

30-005-60527

C-17-85-29c.

M.E.W. Enterprises.

O'Brien Deming #1

Tops

T. SALT 1115'

B. SALT-1650'

T. Queen - 1660'

T. SA. - 2130'

* Perforate 5 1/2" casing @ 30'.

Circulate cement to surface.

* Perforate 5 1/2" casing @ 243'. Squeeze 100' cement Plug.

Inside + Outside 5 1/2" casing. TAG

* perf. 5 1/2" casing @ 1115' Squeeze cement plug + TAG

* Perforate 5 1/2" casing @ 1750'. Squeeze 100' cement Plug.

Inside + Outside 5 1/2" casing. TAG

* Circulate Brine Gel.

* Run + set CIBP @ 2791'. w/ 35' cement.

* Perfs 2868'-93'

5 1/2" casing

3029'

w/ 1005' cement

ROC - 2200' Cal.

MS