Charles HarleDATELOCATION ULSTR)5/30/95B-32-6-26API NO. 30-005-60591B-32-6-26Run in bole with wireline probe tag cement at 250'. If not, cltag cement at 250'. If not, cllevel. If level is low prepare	heck hole for fluid e to fill hole from	FOOTAGE 330 FNL 2310	FEL
API NO. 30-005-60591 Run in hole with wireline prob tag cement at 250'. If not, c	Linda San And e and see if we heck hole for fluid e to fill hole from		
tag cement at 250'. If not, c	heck hole for fluid e to fill hole from		
	e to fill hole from		
TEACT. IT TEACT TO TOW DICDOR			
TD to surface with ready mix c			
			8 5/8 @ 330'
ASING RECORD:			TD 450'
8 5/8 set at 330' and cement c:		•	
TD at 450' with crooked hole be	elow 330'.		