

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	<input checked="" type="checkbox"/>
FILE	<input checked="" type="checkbox"/>
U.S.G.S.	
LAND OFFICE	
OPERATOR	<input checked="" type="checkbox"/>

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease
State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.

## SUNDRY NOTICES AND REPORTS ON WELLS

DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator JFG ENTERPRISES	8. Farm or Lease Name Lucky Todd
3. Address of Operator P.O. Box 100, Artesia, N.M. 88210	9. Well No. 1
4. Location of Well UNIT LETTER M 660 FEET FROM THE South LINE AND 660 FEET FROM THE West LINE, SECTION 18 TOWNSHIP 7 S RANGE 29 E NMPM.	10. Field and Pool, or Wildcat Bull's Eye San Andres
15. Elevation (Show whether DF, RT, GR, etc.) GR 4032	12. County Chaves

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- Spot 25 sacks cement across perfs at 2580' - Tagged plug on perfs @ 2390'
- Load Hole w/Salt Gel - Shot 4½" Casing @1710' - Pull casing out of hole.  
Spot 35 sacks cement across 4½" stub - Tagged plug @ 1650'.
- Spot 35 sacks cement @ 1600' across base of salt.
- Spot 50 sacks cement @ 476' (50' below 8 5/8" shoe) - 4 hrs. later tagged plug @ 360'
- Spot 5 sacks cement @ surface - Erect Dry Hole Marker
- Level pits and clean location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED A. B. Fletcher TITLE Agent DATE 3-7-84

APPROVED BY Kenny Brooks TITLE Geologist DATE 7-26-85