

Plugging Procedure
George J. Crosby
Wilson # 1
Sec. 13-10-24 Ut. E

1. Rig up unit, pick up tbg. & run in hole & attempt to locate T.D. below 42' by using a bit or notched collar & rotate tbg.
2. Fill hole with cement from T.D. to surface by circulating cement.
3. Set P&A marker, clean & level location.