

Operator McClellan Oil Corp.
 Well Paula Federal #1
 Unit E Section 12 Township 14 Range 28
 API # 30-00S-61875

TOPS

Queen 1312
Grayburg 1730
San Andres 1915

← 60' surface Plug

- * Contact OCD 24 hrs. prior to any work done.
- * Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
- * Install dry hole marker as per Rule 202.B.2
- * Plugs are to be set from point indicated up.
- * Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- * Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- * Surface plug will be from 0' - 60'
- * Where plugs are required, cement must be placed inside and outside of all casing string(s) in the correct footage or sacks required, if no cement exists.
- * Plugs to be tagged will be indicated.

10 3/4" @ 297'
 220 SXS
 CUC
 2

800'

← 170' - 170' Shoe Plug
 TAG

TOP @ 509'

← 1820' - TAG

1872' - 1898' — Pufs

2650' C-JABO →

2745' - 2798' — Pufs

4 1/2" @ 2973'
 750 SXS
 7 7/8 hole