

COMPANY <i>Sandco Oil & Gas Inc</i>		PROPERTY NAME <i>O'Brien-Lighttrap "7" #1</i>		WELL NO. <i>1</i>
DATE <i>7-8-29 ut. N</i>	LOCATION (ULSTR) <i>7-8-29 ut. N</i>		FOOTAGE <i>660FS + 1980FWL</i>	
API NO. <i>30-005-62021</i>		POOL <i>Bulls Eye San Andres</i>		
1. Spot a 25 SX plug @ 2715' WOC + Tag 2. Spot a 25 SX plug @ 2100' 3. Perforate 4 1/2 @ 200' + circulate cont to surface behind pipe + leave 4 1/2 full. 4. Set P+ A marker 5. Cut anchors, clean & level location 6. Place mud between plugs @ 25 lb per/bbl of brine water.			<i>After</i>	
CASING RECORD: <i>8 5/8 @ 120' 6 Cyps Ready mix 11" hole</i> <i>4 1/2 @ 2810' 175 SX 7 7/8 hole</i> <i>Perfs 2714'</i> <i>Est TOC @ 2087'</i>				