

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO.

5. Indicate Type of Lease  
STATE ☐ FEE ☒

6. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"  
(FORM C-101) FOR SUCH PROPOSALS.) RECEIVED

1. Type of Well:  
OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. Name of Operator *Baber Well Servicing* MAR 24 '89  
Rhymes Drilling Co., Inc.

3. Address of Operator  
P. O. Box 729, Roswell, NM 88201 O. C. D. ARTESIA OFFICE

4. Well Location  
Unit Letter C : 990 Feet From The North Line and 1650 Feet From The West Line  
Section 19 Township 8 South Range 29 East NMPM Chaves County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)  
3985.7 GR

7. Lease Name or Unit Agreement Name  
O'Brien "19"

8. Well No.  
2

9. Pool name or Wildcat  
Twin Lakes San Andres

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>		CASING TEST AND CEMENT JOB <input type="checkbox"/>	
OTHER: <input type="checkbox"/>		OTHER: <input type="checkbox"/>	

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Move in rig up. Rig up wireline and set 4½" CIBP @ 2600'.
2. Load hole with mud and spot 7 sks. of cement on CIBP.
3. Cut and pull casing @ 1575'.
4. Spot 25 sks. of cement @ 1630' stub. Tag @ 1522'.
5. Spot 25 sks. of cement @ 975'.
6. Spot 50 sks. of cement @ 175' to surface.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE *Raymond Maldonado* TITLE P & A Supervisor DATE 3-20-89  
TYPE OR PRINT NAME Raymond Maldonado - Baber Well Servicing Co. TELEPHONE NO. 505-397-3502

(This space for State Use)

APPROVED BY *Johnny Robinson* TITLE OIL AND GAS INSPECTOR DATE 5-11-90  
CONDITIONS OF APPROVAL, IF ANY: