

Operator Petroleum Development
 Well Isler Pennzell Federal #3
 Unit 6 Section 3 Township 7 Range 26
 API # 30-005-62154

TOPS

San Andrus	850'	*
Gleniera	1630'	*
Tubb	2770'	
Abc	3963'	*

Plug 0-60' Surf.

← 400'

- * Contact OCD 24 hrs. prior to any work done.
 - * Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
 - * Install dry hole marker as per Rule 202.B.2
 - * Plugs are to be set from point indicated up.
 - * Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
 - * Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
 - * Surface plug will be from 0' - 60'
 - * Where plugs are required, cement must be placed inside and outside of all casing string(s) in the correct footage or sacks required, if no cement exists.
- Plugs to be tagged will be indicated.

8 5/8" @ 841'
 350 SXS
 circ?

← Plug 851' - TAG

← 3400' — TOC

← Plug 4338'

Ref 4388' - 4390'

4 1/2" @ 4364'
 700 SXS
 —

← Plug 4500' TAG

[Handwritten signature]