

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	<input checked="" type="checkbox"/>
FILE	<input checked="" type="checkbox"/>
U.S.G.S.	
LAND OFFICE	
OPERATOR	<input checked="" type="checkbox"/>

OIL CONSERVATION DIVISION

P. O. BOX 2
SANTA FE, NEW MEXICO 87501

RECEIVED BY
MAR 25 1985
O. C. D.
ARTESIA, OFFICE

Form C-103
Revised 10-1-78

5a. Indicate Type of Lease
State ☐ Fee ☒
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Dry		7. Unit Agreement Name
2. Name of Operator Petrus Operating Company, Inc. ✓		8. Farm or Lease Name Moon Company 34
3. Address of Operator 12201 Merit Drive, Suite 900 Dallas, TX 75251		9. Well No. 1
4. Location of Well UNIT LETTER I 1980 South 660 THE East LINE, SECTION 34 TOWNSHIP 7S RANGE 29E NMPM.		10. Field and Pool, or Wildcat Wildcat-S.A.
15. Elevation (Show whether DF, RT, GR, etc.) 4105' GL		12. County Chaves

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☐
OTHER ☐

PLUG AND ABANDON ☒
CHANGE PLANS ☐
OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐
COMMENCE DRILLING OPNS. ☐
CASING TEST AND CEMENT JOB ☐
OTHER ☐
ALTERING CASING ☐
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

To plug and abandon the above well we propose to:

1. Cement squeeze the perms from 2889-3024' with cement leaving the top of cement at or above 2800' with 50 sx of cement. TOC will be tagged.
or CIBPW/35' cmt.
2. Cut and pull the 4-1/2" casing at ±2250'.
3. Spot a 250' cement plug across the stub and top of the San Andres (2337' ELM) from 2150-2400' with 60 sx of cement. TOC will be tagged.
4. Spot a 100' cement plug across the top of the Queen (1949' ELM) from 1900-2000' with 40 sx of cement. TOC will be tagged.
5. Spot a 100' cement plug across the 8-5/8" casing shoe from 480-580' with 40 sx of cement. TOC will be tagged.
6. Spot a 15 sx surface plug.
7. Cut the 8-5/8" casing off 4' below ground level and install a 4" OD permanent marker.

Notify N.M.O.C.C. in sufficient time to witness

Plugging

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED C. L. Hardy C. L. Hardy TITLE Drilling & Production Mgr. DATE 03-18-85
Original Signed By
Leslie A. Clements
Supervisor District II
APPROVED BY _____ TITLE _____ DATE MAR 27 1985
CONDITIONS OF APPROVAL, IF ANY:

PETRUS OPERATING COMPANY, INC.
 MOON COMPANY "34" NO. 1
 CHAVES COUNTY, NEW MEXICO
 1980' FSL & 660' FEL OF S-34, TWP-75, R-29E

PROPOSED P&A

