

PLUGGING PROCEDURE

Aciete Negra #4

PLUG #1 25 sacks from 6,506' to 6,289' (from PBTD covering perfs and through top of Mississippian). *Tag plug.*

PLUG #2 25 sacks from 5,700' to 5,483' (covering top of the Pennsylvanian into ABO).

Cut casing approximately 4,400' and pull.

PLUG #3 25 sacks from 4,500' to 4,355' (covering 100 feet within the production casing and 45 feet outside of production casing for the purpose of plugging casing stub.) *Tag plug.*

PLUG #4 40 sacks from 1,700' to 1,563' (covering 57 feet below the end of the surface casing and 80 feet within the surface casing. This plug would also cover the top of the San Andres. *Tag plug.*

PLUG #5 30 sacks from 100 feet to surface.

Place dry hole marker at surface, clean and reseed location.

