

Operator CJM. C Co.
Well Yates Brown St #1
Unit I Section 27 Township 10 Range 26
API # 30-0 05-- 62250

TOPS

Yates _____
T. Salt _____
B. Salt _____
Glorieta _____
Bone Sp. _____
Abo _____
Wolfcamp _____
Morrow _____
Devonian _____
Fusselman _____
Other Queen 453

60' 50' 40' 30' 20' 10' 0'

- Contact OCD 24 hrs. prior to any work done.
- Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug
- Install dry hole marker as per rule 202.B.2
- Plugs are to be set from point indicated up. Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater.
- Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- Surface plug will be from 0' - 60'
- Where plugs are required cement must be placed inside and outside of all casing string(s), in the correct footage or sacks required, if no cement exists.
- Plugs to be tagged will be indicated.

60' 50' 40' 30' 20' 10' 0'

60' 50' 40' 30' 20' 10' 0'

4 1/2"

10' 50' 40' 30' 20' 10' 0'